

Safety Information

READ AND SAVE THESE INSTRUCTIONS.

- For your protection and safety, carefully read and understand the information provided in this manual completely before attempting to assemble, install, or operate this product. Failure to do so could lead to electrical shock, fire, or other injuries that could be hazardous or even fatal.
- Before touching any wire, use a voltage tester to make sure it is not live.
- When replacing fuses, turn off the main power rst. Make sure your hands and feet are dry, and place one hand behind your back to prevent electricity from making a complete circuit through your chest. Touch the plug fuse only by its insulated rim. Remove the cartridge fuses with a fuse puller.
- Use tools with insulated handles and ladders made of wood or fiberglass.
- To protect children, place a safety cover over any unused outlets.



DANGER: Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker, removing the fuse at the fuse box, or tripping the breaker that controls that circuit. Tape a sign to the panel warning others to leave the circuit alone while you work.



CAUTION:Consult a qualied electrician if you have any electrical questions. If you have any non-electrical questions about this fixture, Please contact us via email: 417186486@qq.com
Please reference the model and item numbers.

Warranty

ONE YEAR WARRANTY

WHAT IS COVERED


The manufacturer warrants this fixture to be free from defects in materials and workmanship for a period of one year from the date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, tl manufacturer' s only obligation and your exclusive remedy, is the repair or replacement of the product at the manufacturer' s discretion, provided that the product has not been damaged through misuse, abuse, accident, modications, alteration, neglect, or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the nish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear.

WHAT IS NOT COVERED

The manufacturer does not warrant and specically disclaims any warranty, whether expressed or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor/expense costs involved in the replacement or repair of said product.


▼Installation Instruction

►Tools required for installation:



1. Install the fixtures in the order shown at right.
- The order of installing the fixtures is shown in the figure on the right. ①→②→③→④→⑤
2. ① Fix the canopy to the ceiling. Install the remaining wires into the canopy and store them, Fasten the canopy to the ceiling with screws and copper caps.
3. ②Wiring Connect the energized conductor of the lamp power cord to the energized conductor of the junction box on the ceiling.
Wiring. Connect the neutral and neutral wires together.
4. ③ Secure the ceiling tray mounting with the trim.
4. ④ Install the light bulb.
5. ⑤ Install the crystal.

Instruction



[Note: The light body must be firmly installed].