


ASSEMBLY INSTRUCTIONS

WF286609/WF286610
TRIPLE BUNK BED



! SAFETY WARNINGS !

1. This bed is designed for use only mattress(es) meeting the following specifications on the upper bunk, and lower bunk:

Bed Type	Length	Width	Thickness
Twin Standard	74" - 75"	38 1/2"	6"

- 2. Replacement parts, including additional guardrails, may be obtained from any of our (GIGACLOUD TECHNOLOGY (USA) INC . 18961 ARENTH AVENUS CITY OF INDUSTRY, CA, 91748) dealers
- 3. Follow the information on the warnings appearing on the upper bunk bed end structure and on the carton. Do not remove warning label from bed.
- 4. Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.
- 5. Surface of the mattress must be at least 5 in. (127 mm) below the upper edge of guardrails.
- 6. Do not allow children under 6 years of age to use the upper bunk.
- 7. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
- 8. Do not allow horseplay on or under the bed and prohibit jumping on the bed
- 9. Always use the ladder for entering and leaving the upper bunk.
- 10. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
- 11. Use of a night light may provided added safety precaution for a child using the upper bunk.
- 12. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
- 13. The use of water or sleep flotation mattresses is prohibited.
- 14. STRANGULATION HAZARD – Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hook, belts and jump ropes.
- 15. Keep these instructions for future reference
- 16. Prohibit more than one person on upper bunk
- 17. We recommend assembling your bunk bed on a shipping carton to protect your floor or carpet
- 18. Be certain all staples are out of the box before beginning assembly on the shipping carton

1. **At the beginning :**
Tighten all hardware.

Check metal parts for rust. If found, sand and repaint using a non-lead-based paint meeting the requirements of 16 CFR 1303.


Check all wood members for deterioration and splinters. Sand down splinters and replace deteriorating wood members.

Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.
2. **Twice a month**


Tighten all hardware.

Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.
3. Owners shall be responsible for maintaining the legibility of the warning labels.
4. **Disposal Instructions**-There shall be instructions advising the owner to disassemble and dispose of the playground equipment in such a way that no unreasonable hazards will exist at the time the playground equipment is discarded.
5. The instructions shall also include the information found in Section 4 of the United States Consumer Product Safety Commission's (USCPS) Outdoor Home Playground Safety Handbook or specific surfacing guidelines for the product consistent with the USCPS Handbook. A copy of this section may be found in Appendix X2.
6. Observing the following statements and warnings reduces the likelihood of serious or fatal injury.
7. Specifying the number and weight of occupants that may safely use the equipment singly or simultaneously,
8. Recommending on-site adult supervision for children of all ages,
9. Warning the owner to instruct children not to use the equipment in a manner other than intended,
10. Warning the owner to instruct children not to get off equipment while it is in motion,
11. Warning the owner not to allow children to wear inappropriate items, such as but not limited to, loose fitting clothing, hood and neck drawstrings, scarves, cord-connected items, capes and ponchos. These items can cause death by strangulation.
12. Warning the owner to instruct children not to climb when the equipment is wet.
13. Warning the owner to instruct children not to attach items to the playground equipment that are not specifically designed for use with the equipment, such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard
14. Warning the owner to instruct children to remove their bike or other sports helmet before playing on the playground equipment.
15. Warning the owner to dress children with well-fitting and full foot enclosing footwear. Examples of inappropriate footwear are clogs, flip flops, and sandals.
16. Place the equipment on level ground, not less than 6 ft (1.8 m) from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires
17. Do not install home playground equipment over concrete, asphalt, packed earth, grass, carpet, or any other hard surface. A fall onto a hard surface can result in serious injury or death to the equipment user
18. To prevent serious injury, cautionary statements shall be included which warn that children must not use the equipment until properly installed.







Detail View



Detail View




Part List: WF286610

1  Front left leg - 1pc	2  Back left leg - 1pc	3  Front right leg - 1pc
4  Back right leg - 1pc	11  Front horizontal - 2pcs	12  Back horizontal - 4pcs
13  Front vertical (left) - 2pc	14  Front vertical (right) - 1pc	16  Back vertical - 3pc
31  Left stairs vertical - 1pc	25  Front left leg - 1pc	26  Back left leg - 2pcs
8  Horizontal (lower) - 2pcs	28  Back right leg - 1pc	32  Right stairs vertical - 1pc
20  Left slide vertical - 1pc	9  Front side rail - 1pc	10  Back side rail - 2pc
21  Right slide vertical - 1pc	23  Slide support bar (bottom) - 1pc	24  Slide panel - 1pc
36  Side vertical - 1pc	30  Front horizontal - 2pcs	29  Front side rail - 1pc

Hardware List: WF286609




A  Ø10*30mm Wood dowel (134pcs)	B  Ø1/4**30mm Hex-Head bolt (8pcs)	C  Ø1/4**65mm Hex-Head bolt (6pcs)
D  Ø1/4**85mm Hex-Head bolt (34pcs)	E  Ø1/4" Horizontal-Hole bolt (40pcs)	F  Ø1/4" Nut (8pcs)
G  Ø6*30mm Hex-Head screw (9pcs)	H  Ø6*50mm Hex-Head screw (31pcs)	I  Ø6*100mm Hex-Head screw (19pcs)
J  Hook (10pcs)	K  #4*20mm Screw (30pcs)	L  #4*30mm Screw (56pcs)
M  K4mm Allen key (2pcs)	O  Ø10*90mm Metal dowel (4pcs)	Q  90*17*2mm Foam stick (10pcs)
R  Ø1.5*10mm Feathers warped (12pcs)		

ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)




PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE
POSITION WHEN YOU USE POWER TOOLS !

Part List: WF286609

35  FB horizontal (upper) - 1pcs	35A  FB horizontal (upper) - 1pcs	22  Slide support bar - 4pcs
19  Stairs support bar - 9pcs	17  Left stairs vertical - 1pc	18  Right stairs vertical - 1pc
7  HB-FB horizontal (upper) - 3pc	6  HB-FB horizontal (middle) - 3pc	5  HB-FB horizontal (lower) - 3pcs
34  FB horizontal (middle) - 1pc	5A  HB-FB horizontal (lower) - 2pcs	15  Slat - 28pcs

STEP 1:


A	I
	
14PCS	10PCS



NOTE: In this step, DO NOT tighten any bolt until you connect all part together

STEP 2:


A	H
	
3PCS	1PC



NOTE: In this step, DO NOT tighten any bolt until you connect all part together

STEP 3:


A	B
	
3PCS	2PCS
F	I
	
2PCS	1PC



NOTE: In this step, DO NOT tighten any bolt until you connect all part together

STEP 4:

A	D
	
16PCS	20PCS
E	
	
20PCS	




ATTENTION: PLEASE DON'T TIGHTEN ALL BOLTS IN THIS STEP, JUST TIGHTEN 80%

NOTE: In this step, DO NOT tighten any bolt until you connect all part together

STEP 5:


G	
3PCS	



NOTE: In this step, DO NOT tighten any bolt until you connect all part together

STEP 6:

A		C	
8PCS		4PCS	
E			
4PCS			




NOTE: In this step, DO NOT tighten any bolt until you connect all part together

11

STEP 7:


B		F	
4PCS		4PCS	



NOTE: In this step, DO NOT tighten any bolt until you connect all part together

STEP 8:

A		H	
12PCS		6PCS	




NOTE: In this step, DO NOT tighten any bolt until you connect all part together

12


STEP 9:

Q	J	K
4PCS	4PCS	8PCS



STEP 10:


K
4PCS



13


STEP 11:

R	A	H
12PCS	8PCS	12PCS





STEP 12:

Q	J	K
2PCS	2PCS	4PCS





14

STEP 13:





STEP 14:





15

STEP 1:



NOTE: In this step, DO NOT tighten any bolt until you connect all part together

STEP 2:




ATTENTION: PLEASE DON'T TIGHTEN ALL BOLTS IN THIS STEP, JUST TIGHTEN 80%

NOTE: In this step, DO NOT tighten any bolt until you connect all part together


16

STEP 3:



NOTE: In this step, DO NOT tighten any bolt until you connect all part together


STEP 4:



NOTE: In this step, DO NOT tighten any bolt until you connect all part together


17

STEP 5:



NOTE: In this step, DO NOT tighten any bolt until you connect all part together


STEP 6:



NOTE: In this step, DO NOT tighten any bolt until you connect all part together


18

STEP 7:




A	H
	
24PCS	12PCS

STEP 8:



Q	J	K
		
4PCS	4PCS	8PCS


STEP 9:



O

4PCS

STEP 10:



K

4PCS

COMPLETED

