


USER MANUAL




Electric Smart Sofa




Return & Warranty policy:

-- We strive to offer the highest quality products, and we also try our best to satisfy each and every customer that orders from us with replacement parts or service as needed.


-- If the item is damaged or defective, please take photos as evidence for replacements and refunds.




Caution: Do Not Exceed Maximum Listed Weight Capacity
Serious Injury Or Property Damage May Occur!




BOX A




A x1




B x1




C x1




BOX B




F x1




D x1



E x1



G x1




H x1

Actual part
may vary.


1

Align the inserts on Part B and Part C with the inserts on both sides of Part F, then press down to connect them.




2

Peel off the wear-resistant cloth strips on the back of Part D and Part E.




3

Connect the zippers on the outer sides of Part D and Part E to Armrest B and Armrest C respectively, then fasten the hook-and-loop fasteners (Velcro) on the inner sides together.




4

Cut off the bundling strap on the latch at the rear end of Seat F, and then take out the chair's remote control.




5

Align the bolts on both sides of Backrest A with those on the seat F, press down firmly, and the installation is complete when a "click" is heard.




6

Connect the connecting wires at the bottom of Backrest A to the connecting wires at the back of Seat Cushion F according to their corresponding colors.




7

Stick the Velcro at the back end of the backrest properly.





8

Connect both ends of Part G to the interface at the back of the chair and Power Cord H respectively.




9

Take out the chair's controller.
Press the buttons to activate the chair's recline.



The top of the remote control is equipped with a USB charging port.



- 1、 Plug in the power cord to turn on the power.
- 2、 Press the **ZONE▲** key to activate the backrest recline function, and press the **ZONE▼** key to activate the backrest retract function.
- 3、 Press the **MASSAGE** key to activate the massage function.
- 4、 Press **INTENSITY+ / INTENSITY-** to adjust the vibration intensity.
- 5、 Press **MODE▲ / MODE▼** to cycle through the massage modes.
- 6、 Press **HEAT** to turn the heating cloth function on or off.
- 7、 Press **10'** and the heating cloth will automatically turn off after 10 minutes.
- 8、 Press **20'** and the heating cloth will automatically turn off after 20 minutes.
- 9、 Press **30'** and the heating cloth will automatically turn off after 30 minutes.