





























Assembly Instruction




Accessories list

	Parts	Specification	Carton	Pcs		Parts	Specification	Carton	Pcs
A		6×40mm	1/1	X 16	B		15×11	1/1	X 16
C		12 inches	1/1	X 2	D		8×40	1/1	X 2
E		3.5×14mm	1/1	X 36	F		5×40/#3	1/1	X 20/1
G		68×70	1/1	X 4	H		600Wooden leg	1/1	X 4
J		400Wooden leg	1/1	X 4	K		4×18mm	1/1	X 2
L		21mm	1/1	X 20	M		6×25/8×14	1/1	X 8
N		Handle	1/1	X 2	P		USB	1/1	X 1


Company: (mm)

1		X1	800x400	1/1	2		X1	800x380	1/1
3		X1	380x120	1/1	4		X1	380x120	1/1
5		X1	364x120	1/1	6		X1	768x120	1/1
7		X2	372x116	1/1	8		X2	300x85	1/1
9		X2	300x85	1/1	10		X2	322.5x85	1/1
11		X2	331.5x293	1/1	12		X1	449x400	1/1
13		X1	350x230	1/1					


1



2





3





Hx4 Mx8

4




Ex4 CLx1 CRx1

5





Ex4 CLx1 CRx1

6





Fx12 Lx4

7




Ax8

8



Bx8 Lx8


9



Fx8

X2


10



Ax8 Bx8 Lx8 Nx2 Kx2

X2


11




Ex8 DLx2 DRx2

X2

12




13




Dx2 Fx2

14



Px1

15



Ex20 Gx4 Jx4

16

