
ASSEMBLY INSTRUCTIONS
USER'S MANUAL
2PCS CORNER SOFA



Please keep
this instruction manual for future reference

CORNER SOFA

NOTES TO CUSTOMERS:

- Please check that your parcel contains all the parts listed below.
- Please keep all the packaging for the product until you are satisfied with your purchase as we cannot accept any returned item not in the original packaging.
- For the protection of your furniture we recommend that the product is placed on a protected surface during assembly to prevent any damage.
- Please ensure that you read the instructions before assembling the product.
- Please do not force or over tighten the nuts. If a nut becomes stuck, unscrew it and start again.
- Ensure you have plenty of space to assemble the item in, it is also recommended that you assemble the item close to where it will be kept.
- Please ensure that you have sufficient space and people to assemble the item.

CORNER SOFA ASSEMBLY STEPS



The parts and hardwares below have been included for assembly




(A)x1PCS



(B)x1PCS



(C)×1PCS




M6x35 9PCS



(L)×1 Wrench


ASSEMBLY STEPS

1



Step 1: Match the two(2) holes of parts A and B. Insert the screws and twist by L. Do not fully tighten all screws until assembly is complete.

2



Step 2: Match the four(4) holes of parts C and A. Match the three(3) hole of parts C and B.Insert the screws and twist by L. Do not fully tighten all screws until assembly is complete.

Screws Assembly Steps

1




match the two different holes

2



insert screws

3



tighten the screws by included wrench

Important: Do not fully tighten all screws until assembly is complete.

CARE AND MAINTENANCE

- This set has been tested for a maximum load of 300 lbs static weight only.
- Please ensure that all components are fitted correctly before use of the product.
- Under no circumstances should you abruptly sit or jump on the product.
- Do not stand or kneel on the product.
- Please check the assembly works before you sit on the product.
- Make sure all the screws and bolts are tightened properly.
- Periodically check all fixings to ensure they remain secure.
- Prolonged exposure to the elements will inevitably lead to weathering – store away indoors throughout winter to preserve appearance.
- Do not leave the furniture out in excessively windy conditions as the furniture is light and may blow away.
- Clean using a mild detergent – do not use abrasive cleaners