




## Premier Reversible Arch Rack PR37

If you need assistance, please call 1-877-ENCLUME  
**Enclume Design Products**  
24 Colwell Street, Port Hadlock, WA 98339




Enclosed you will find everything needed for the assembly and use of your ceiling rack. Two people make assembly and installation easier. The parts and hardware included are:

### Hardware included:

2 – Ceiling Screw Hooks  
2 – 2" 'S' Hooks  
Toggle Kit

### Components included:

1 – Rack Body  
2 – Hanging Arms  
12 – Straight Pot Hooks - WSPHS



## ASSEMBLY AND INSTALLATION INSTRUCTIONS

### Rack Assembly

- 1) Place rack body on a firm surface.
- 2) Locate the hanging arms. Connect arms to the rack body by placing the ends under the appropriate cross bars as shown in the picture.
- 3) Measure and mark the location for the two ceiling screw hooks on the ceiling to hold rack hanging arms.
- 4) The rack may be anchored into solid wood, (ceiling or roof joist, beam or backing that is designed to support the weight of your rack along with your cookware) using the two ceiling screw hooks provided. If you decided to mount in plasterwall, use the Toggles provided, and follow the directions in the Toggle kit.
- 5) Using the 'S' hooks provided hang the rack by hooking one end of the 'S' hook over the arm and the other end over the ceiling screw hook that has been anchored securely into solid wood. Repeat process for other side.
- 6) If at any time you wish to reverse the rack, simply turn it over and repeat above. It is best to hang your pots on the crossbars to prevent sliding.

**WARNING:** It is important that your ceiling rack is assembled correctly. If the unit is assembled or used incorrectly, it could become unstable and collapse, possibly causing injury.

**LIMITED WARRANTY:** This product is warranted to be free of material defects, other than that from normal use, for a period of five years from the date of purchase. Customer's exclusive remedy shall be the repair or replacement of the defective product and shall be subject to the following conditions: (1) notice of any defect is received by Enclume within the warranty period and (2) customer returns the defective product to Enclume Design Products, 24 Colwell St., Port Hadlock, WA 98339, postage prepaid within 20 days following a return authorization number (which may be obtained by telephoning the number at the top of this instructions) being provided to the customer by Enclume. There are no other warranties, expressed or implied. THERE ARE NO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ENCLUME SPECIFICALLY DISCLAIMS ANY AND ALL INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE PURCHASE OR USE OF ENCLUME'S PRODUCTS.