


Power Recliner Chair with Waist Pillow


Instruction Manual



Thank you for choosing this product.




Manual controller instructions



Operating Instructions

	Press the " △ "key, and the sofa gradually unfolds.
	Press the " ▽ " key, and the sofa gradually retracts.
M1	Tap the " M1 " key once, and the sofa moves to the lying position.
M2	Tap the " M2 " key once, and the sofa moves to the sitting position.
Reset	Press the " M1 + M2 " keys for a long time until the sofa starts to retract and reset. After the reset is complete, the sofa returns to the sitting position.

SPECIFICATIONS



Caution: Do Not Exceed Maximum Listed Weight Capacity. Serious Injury Or Property Damage May Occur!



Load Capability
136kg(300lbs)



Power Input
110v-240v



Official After-sales Channels

Account & Lists


Describe your problem

Orders-Get help with order

Send e-mail
jjoyseeker@outlook.com


Choose your problem

COMPONENT LIST




The sofa is tidied up before use



The sponge requires rebound time after compression, which can be patted to correct the position and accelerate rebound




Attention

Error example





TIP: Align and attach the hook and loop fasteners for a secure connection.



COMPONENT LIST

01



Right Armrest x 1

02



Left Armrest x 1

03



Right Recliner Wing x 1

04



Left Recliner Wing x 1

05




Seat Cushion x 1

06




Padded Backrest x 1

07




Recliner base x 1

08



Manual Controller x 1

09



Power Cord x 1

10



Lumbar Pillow x 1

HARDWARE LIST

A



Recliner Base Foot x 4

B



Anti-slip Mat x 4

B



Anti-slip Mat x 1

SPARE PARTS

STEP 1: Install the Base Feet

Step1-1

Attach anti-slip mats

A




Recliner Base Foot (x4)

B




Anti-slip Mat(x4)




Step1-2


Install the base feet




STEP 6: Install the Recliner Wing




STEP 7: Attach the Hook-and-Loop Tapes



STEP 4: Connect the Power Cord and Manual Controller




STEP 5: Install the Padded Backrest




STEP 2: Install the Seat Cushion

Step 2-1




Step 2-2



Step 2-3

Assemble the column to the base




STEP 3: Install the Armrests

Step 3-1

Tip for installing the buckle

Have another person squat on the opposite side of the sofa and pull the cushion toward themselves, so that the buckle is fully exposed and the armrest can be inserted more quickly.



Step 3-2

