

## 3 Pk Adjustable Height Lamp Set

### Questions?

E-mail our customer service department

### IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other). As a safety feature to reduce the risk of electrical shock and fire, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter this safety feature.

This lamp is for indoor use only. The lamp should not be used near water. Never immerse the lamp in water or other liquids. Never cover the lamp with any object including cloth or paper as this is a fire hazard. Do not handle the bulb immediately after the light is turned off as it will be hot. This is not a toy.


### ASSEMBLY INSTRUCTIONS:

#### TABLE LAMP:

1. Screw pole (A) into Base (B).
2. Place shade (C) onto Socket (D).
3. Adjust the height of the table lamp by removing screw (E) replace and tighten once desired height is achieved.  
*(You will need to pull the cord through the base to lower the height and/or bring the cord up by pulling the adjustment pole up when fully extending the lamp.)*
4. Install bulb. Only use bulbs of specified type and maximum rated wattage or less.
5. Plug the electrical supply cord into the wall outlet.
6. Turn ON/OFF using the switch on the socket.

#### FLOOR LAMP:

1. Screw pole (A) to base (B), then screw pole (C) to pole (A).
2. Screw pole (D) to pole (C), then screw lamp holder (E) to pole (D).
3. Place shade (F) onto socket (G).
4. Adjust the height of the floor lamp by removing screw (H) replace and tighten once desired height is achieved.  
*(You will need to pull the cord through the base to lower the height and/or bring the cord up by pulling the adjustment pole up when fully extending the lamp.)*
5. Install bulb. Only use bulbs of specified type and maximum rated wattage or less.
6. Plug the electrical supply cord into the wall outlet.
7. Turn ON/OFF using the switch on the socket.



Each Requires 1 x 100W 3-Way Type A Medium Base bulb (not included)



### CLEANING & MAINTENANCE:

1. Unplug the fixture before cleaning.
2. Use a clean, dry, soft, lint-free cloth.
3. Do not use water or other chemical cleaning agents.

## LIMITED WARRANTY

---