

INSTRUCTION MANUAL



WARNING



Please read the instructions carefully and follow the assembly steps.

To ensure proper assembly, please follow all steps and use all parts provided. Not following this warning may result in serious injury to you or others.

To prevent misalignments, keep the screws loose and do not tighten them until they are all in their correct positions.

Avoid overtightening or forcing the screws, as this could cause them to break, strip, or damage the threads of the holes.

Using the wrong size of screws for a particular part could cause damage to the screw or the part.

Please lubricate all moving parts regularly and tighten all bolts and screws every 6 months, or as needed.

SAFETY INFORMATION

WEIGHT CAPACITY FOR SEATING: 300 LBS



Sit in the center of the chair with your back against the backrest



Do not sit at the front edge of the chair



Do not stand on the chair



Do not use the chair with more than one person



Do not push the chair around when a person is sitting in it



Do not push down on the backrest when a person is reclined



Do not place all your weight on the backrest only

ASSEMBLY PARTS AND TOOL

BEFORE YOU GET STARTED, A FEW POINTERS:



Having a friend to help makes assembly extra-easy




Please use the included wrench instead of an **ELECTRIC HAND DRILL** in case of damage to the product.

A



Caster *5

B



Star Base *1

C



Gas Lift *1

D




Deco-ring *1

E



Seat Cushion*1

F




Arms *1

G



Back Cushion *1

H



Seat Plate *1

I



Bolts M6*20mm *4

J




Bolts M8*35mm *8

K



Flate Washer *8

L



Wrench * 1

PLEASE MAKE SURE ALL THE PARTS ARE INCLUDED.


MISSING PARTS? support@colamyhome.com

ASSEMBLY INSTRUCTIONS

Tips: 1. Please do the assembly on a clean and flat surface, to avoid the chair getting dirty.
2. Please do not 100% tighten all the bolts until the chair is fully assembled, just 50% is OK, make it has space to adjust the chair.

Step 1


Turn Star Base B upside down, press Five Casters A into the holes at the end of each base leg.
Then insert Deco-ring D and Gas Lift C into Star Base B.



ASSEMBLY INSTRUCTIONS

Step 2

Attach Right Arm F and Back Cushion G to Seat Cushion E, align the screw holes on the arm & back cushion with seat cushion, using Four M8*35mm Bolts J including Flat Washer K, tighten the bolts to 50% by Wrench L.
Note: Arms are marked with Letter "L" (left) or "R" (right) to show which sides they should be placed on.




ASSEMBLY INSTRUCTIONS

Step 3

Do the same way for left side, after that fully tighten all the bolts by Wrench L, then zipping up the bottom of the two arms.


Note: Arms are marked with Letter "L" (left) or "R" (right) to show which sides they should be placed on.



ASSEMBLY INSTRUCTIONS

Step 4


Attach Seat Plate H to the bottom of Seat Cushion E, using Four M6*20mm Bolts I, tighten by Wrench L.



ASSEMBLY INSTRUCTIONS

Step 5

Put the whole Seat part down onto finished base firmly until the connection is secure.



ASSEMBLY INSTRUCTIONS

Step 6


Now your chair is successfully assembled.



PRODUCT FEATURES


Pneumatic Seat Height Adjustment

Pulling the lever upwards enables height adjustment of the seat, then the seat can be locked at a fixed height by releasing the lever.




Rock Tension Adjustment

Simply adjust the knob counterclockwise to tighten the tension of rocking. Or loosen the tension by turning the knob clockwise whenever needed.



Seat Back Locking Mechanism

Pull out to unlock the tilt, push in to lock the tilt at upright position.



LIMITED WARRANTY

promises to repair or replace any chair that is found to be defective in material or workmanship within one year from the date of original purchase so long as you, the original purchaser, still owns it. This is your sole and exclusive remedy. This warranty is subject to the provisions below.

EXCLUSIONS

This warranty does not apply and no other warranty applies to:

LIMITED WARRANTY

- Normal wear and tear, which are to be expected over the course of ownership.
- Misuse, abuse, or excessive use of the product.
- Modifications or attachments to the product that are not approved by COLAMY.
- Products that were not installed, used, or maintained in accordance with product instructions and warnings.
- Products used for rental purposes or unauthorized retail activities.