







AC72950 Assembly Manual

Swivel Accent Chair



CAUTION


THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

A x 1 	B x 1 	
H1 x 4  M6X20mm	H2 x 4  Spring Washer	H3 x 4  Flat Washer
T1 x 1 		


Please read through the instructions below to familiarize yourself with the parts and steps before assembly.

ASSEMBLY INSTRUCTIONS

- 1 Locate the hardware pack attached to the Chair Base (B). Make sure all parts and hardware are present before assembly. Assemble on a soft and smooth surface to prevent damage to product.




- 2 Rotate the swivel plate by 45 degree.




- 3** Attach the Chair Base (B) to Chair Body (A), using Bolts (H1), Spring Washers (H2), and Flat Washers (H3).

Note: **Loosely** attach the bolts one by one and **keep them loose**. **Do not fully tighten**. After all 4 bolts are attached, use Allen Wrench (T1) to tighten.



- 4** Assembly complete. Take a spin and enjoy.



Design Exquisite Furniture For Your Home

PRODUCT WARRANTY

- 1-year limited on cover against splitting, peeling, and/or tearing.
- 1-year limited on internal and external frame structure.
- 1-year limited on cushioning material, seat springs and mechanism.

Contact us:

We make all efforts to guarantee that the products you receive are in excellent condition. If there are any parts missing or damaged, the Customer Service Team will be happy to provide free replacements for you. We have professional warehouses where the current inventory of parts is enough so that they will arrive in your hands as fast as possible.

Assistance with assembly or product details is available; don't hesitate to get in touch with us to get priority service.

Our E-mail address: CS.furniture@outlook.com.



CS.furniture@outlook.com