



Assembly-Free Dog Crate




PS-DC107-31/41


Items in the package:




① Foldable Dog Crate



② Dog Name Tag



③ Dog Bowls




④ Magnetic Paws and Chalks

How to use the tag:

1. Write your dog's name or Christmas blessings with chalk.(Chalks Included)
2. Customize a dog name sticker or Christmas blessings. (Sticker Not Included)
3. Attach the photo of you and your dogs with the magnetic kit.(Magnetic Paws Included)


Step 1

- ① Take the foldable dog crate out of the box.
- ② And then unfold it as illustrated below.



Step 2


- ① Firstly, cut the yellow fixing cable ties with scissors (scissors not included).
- ② Then, put your fingers through the hole on the bottom board and place the board down slowly.



Step 3

There are two locks on the top board, which are used to secure the top board.

⚠ When holding the top board, flip it slowly to avoid pinching fingers !




NOTE:
Press here to unlock

NOTE:
Press here to lock

Step 4



Turn over the bowl holders, and place the two dog bowls.



NOTE: You may find the lock here is not fully aligned. And extra force is needed to lock the latch. Don't worry, we've designed it this way intentionally to avoid the doorlock noise while the dog is eating.

Step 5


NOTE: The bowl holders have two different heights. The lower height for small breeds can only be used outside of the door.



NOTE: Press two ends to attach or remove the holders. Based on your needs, you can adjust it to the proper height.

Step 6

The dog bowl can be placed outside or inside the cage.
Just pull the latch shown in the picture.



These are 4 leveling feet for dealing with the uneven places on the ground.

Installation Completed