
















BSOT-001



ATTENTION:


- 1.Please fix all the screws first,do not lock off,after assembling is fully completed,lock all at once finally.**
- 2.Please check the manual carefully and make sure you have received all the parts.**
- 3.If there is any missing,please let us know the letter of the parts you need.**
- 4.If there is any damage,please send clear photos to us,we will check and offer you best solution soon.**

PARTS LIST

<p>A</p>  <p>2pcs</p>	<p>B</p>  <p>2pcs</p>	<p>C</p>  <p>2pcs</p>	
<p>D</p>  <p>2pcs</p>	<p>E</p>  <p>1pc</p>	<p>F</p>  <p>2pcs</p>	
<p>G</p>  <p>1pc</p>	<p>H</p>  <p>410x410x5mm</p> <p>1pc</p>	<p>I</p>  <p>M6</p> <p>24pcs</p>	
<p>J1</p>  <p>M6x15</p> <p>4pcs</p>	<p>J3</p>  <p>M6x35</p> <p>16pcs</p>	<p>K</p>  <p>1pc</p>	<p>L</p>  <p>2pcs</p>
<p>J2</p>  <p>M6x25</p> <p>4pcs</p>			


ASSEMBLY

1




I:2pcs
J3:2pcs **X2**

2




I:3pcs
J3:3pcs **X2**

3




I:3pcs
J3:3pcs **X2**

4



I:4pcs
J2:4pcs

5



I:4pcs
J1:4pcs

6

