


Halo Split LED Floor Lamp



Assembly Instructions for the Brightech Halo Split LED Floor Lamp:

1. Screw the bottom segment of the pole into the base.
2. Screw the lower middle segment of the pole into the bottom segment.
3. Screw the upper middle segment of the pole into the lower middle segment.
4. Plug the wire protruding from the top pole segment into the upper middle segment.
5. Screw the top segment to the upper middle segment.
6. Screw the head of the lamp to the top segment of the pole.
7. Plug the two segments of the wire together and plug the cord into an outlet.

Extend Your Warranty, Free:

If you would like to extend your warranty from 3 years to 5, free, fill in this short product registration form on our site:

brightechshop.com/pages/extended-warranty

Thankyou!

Thankyou for your order of this Brightech product. If you have any issues with the lamp, we'll be happy to assist you.

Contact us at wecare@brightechshop.com or via our site: www.brightechshop.com