


Assembly Instruction Sheet for Model HL371749

Package Contents

Part	Description	Quantity
A	Ceiling Canopy	1 pc.
B	Fixture Body	1 pc.
C	Metal Shade	1 pc.
D	Mounting Bracket	1 pc.



STEP 1

Take off the lock cap and cord grip from the Ceiling Canopy(A).
Thread the hanging cord of Fixture Body(B) through the lock cap,
cord grip and Ceiling Canopy(A).
Screw the lock cap and cord grip back to the Canopy(A)
to fix the hanging cord of Fixture Body(B).

STEP 2

Remove the socket ring from the lamp socket of Fixture Body(B).
Place the Metal Shade(C) to the lamp socket of Fixture Body(B).
Screw the socket ring back to the lamp socket to stabilize the Metal Shade(C).

STEP 3

Remove the Mounting Bracket(D) from the Ceiling Canopy(A).
Mark the drilling position on ceiling with the help of the Mounting Bracket(D).
Drill holes on the marks and stick the expansion anchors into the holes.
Fix the Mounting Bracket(D) to the expansion anchors with self-tapping screws.

STEP 4

Hold the fixture close to ceiling.
Connect live line to wire color Black/Red from the hanging cord of Fixture Body(B).
Connect neutral line to wire color White/Blue from the hanging cord of Fixture Body(B).

STEP 5

Attach the Canopy(A) to the Mounting Bracket(D).

STEP 6

Insert your bulb to the bulb base.

Your fixture is now assembled and ready to use.