



















CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.


NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List

Ax2 	Bx1 	Cx1 	Dx1 	Ex1 
Fx1 	Gx1 	Hx2 	Ix2 	Jx2 
Kx10 	Lx10 	Mx10 	Nx16  3.5x12mm	Ox8  6x12mm
Px8 	Qx1 	Rx4  3.5x16mm		

Product Dimensions: 39.3"W×19.7"D×29.5"H





PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.


If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 50 minutes.


1




2




3



4



5



6

