



ESPRESSO MAKER
USE, CARE AND SAFETY ADVICE



Care and Use

Stellar Art Deco Coffee Makers are engineered from premium grade stainless steel and are fitted with Filters that will last a lifetime.

Before first use, wash all items in hot soapy water and rinse.

Rinse after every use.

Please refer to the photograph -

- I. Fill the 'BASE' with water up to a level just below the 'VALVE' (see photograph on back page).
- Place 'COFFEE CONTAINER' into base and fill with fine ground Espresso coffee.
- 3. Lightly press the coffee down with the **'TAMPING DISK'**.
- After ensuring the 'TAMPING DISK' is removed, screw fit 'BASE' onto 'TOP JUG' and take to the hob.
- Place the Coffee Maker on a medium heat. After a few minutes, listen for your Espresso coffee transferring under pressure to the 'TOP JUG'.
- 6. Remove from heat and pour when this process has finished.

Spare gaskets are available - 2 cup (SM50G), 4 cup (SM51G), 6 cup (SM52G)

