




# **INSTALLATION**

## *Product Manual*




### **IMPORTANT INFORMATION!**

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.





### **AVOID SCRATCHES!**

In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.



### **IMPROVE EFFICIENCY !**

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



### **ANTI-TOPPLE WARNING !**


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

### **IMPORTANT !**





It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.



Please prepare the following tools




When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 8




Ø6 x 30 mm

B x 2




C x 2



D x 4




E x 4



38 x 12 x 1 mm

F x 2



40 x 20 x 10 mm

G x 2



40 x 20 x 3 mm

H x 2



Ø20 x 23 mm

J x 2




Ø4 x 10 mm

K x 4




Ø8 x 1 mm

L x 2




M x 12




Ø10 x 1 mm

N x 1




75 x 25 x 15 mm

P x 1




Ø4 x 16 mm

Q x 1




LED x 1



x 1



M4




## ⚠ WARNING



**Children have died from furniture tipover. To reduce the risk of furniture tipover:**

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.  
Do not remove!*



ASSEMBLED BY 2 ADULTS

1

A x 4




x 1




M4

Secure part 7 to plate 2 using screw (A).




2

**After the arc-shaped glass 3 is installed, someone needs to hold it firmly throughout the process to prevent it from falling.**




Insert the arc-shaped glass 3 into the arc-shaped groove of the base plate 2, and align the front end of the glass with the front end of the wooden board groove.




# 3

**During this installation process, the other already-installed curved glass still needs to be held by someone to prevent it from falling.**



4


**Someone needs to hold the curved glass on both sides, and then install the glass 4.**




Insert glass 4 into the slot of base plate 2.

5



L x 2






Install the part (L) into plate 1.



6




Connect Panel 1 to the assembly unit and secure Panel 1 to Component 7 using screws (A).




**Until Panel 1 is securely fastened, an adult must continue to hold Glass Panels 3 and 4 in place.**

7

M x 12  
  
 $\varnothing 10 \times 1 \text{ mm}$




Remove the backing tape and attach the rubber pad (M) to the iron frame 7 in the figure.



8



After tilting the laminated glass 5 to the maximum extent, insert it into the iron frame, and then slowly place it on the iron frame one by one as shown.



9





Install the door hinge in sequence onto the door panel 6 as shown.



10




Install the door hinge in sequence onto the door panel 6 as shown.




# 11

B x 1



C x 1




D x 2




LED x 1



First, peel off one side of the protective film from the double-sided adhesive tape on the LED, then peel off the other side of the protective film, and finally attach the LED to Board 1.




LED



1

LED



1

LED

2

C

D

B

D

2






Install Parts (B) and (D) into Plate 2.

# 12

D x 2





As shown in the figure, install glass panel 6 into the assembly in the order shown.




The door hinge must be aligned with the edge of the glass door

# 13

|                                                                                                                      |                                                                                                                       |                                                                                                                      |
|----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------|
| <p>E x 2</p>  <p>38 x 12 x 1 mm</p> | <p>F x 2</p>  <p>40 x 20 x 10 mm</p> | <p>G x 2</p>  <p>40 x 20 x 3 mm</p> |
|----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------|



Peel off the adhesive backing from part (G), attach it to glass 6, and install accessory (F) between part (G) and glass 6.



Insert part (E) into hinges (B) and (C), and secure it with screws.

# 14

H x 2



Ø 23 x 20 mm

J x 2





Ø 4 x 10 mm


K x 4



Ø 8 x 1 mm







Secure the handle (H) to the glass (6) using screws (J) and washers (K).




## Hinge Adjustments

If the door panels do not appear square or aligned, loosen or tighten the appropriate screw as illustrated.



# 16

N x 1








75 x 25 x 15 mm

P x 1




Ø4 x 16 mm


Q x 1




1




1




1.




2.



3.



4.



Install the anti-tip device as shown in the figure.

# WARRANTY

## WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

## Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

## Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

## The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

# RETURNS

## **CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?**

### **PLEASE FOLLOW THE BELOW INSTRUCTIONS:**

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

### **DEFECTIVE ITEMS**

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

### **DAMAGED ITEMS**

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.  
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.