

INSTRUCTION MANUAL

ACCENT CABINET



Estimated Time for Assembly

60 min



Weight Limitation


90 lb overall

50 lb




20 lb


20 lb




Tools Needed (Not included)
Tools Needed (Included)




Tools



Warning



Assemble the furniture on empty carton, carpet, or rug to prevent scratches or damage.













This furniture requires 2 people to assembly.

Make sure no parts are missing or damaged before assembly.







Your cabinet is a 100% handmade decorative product, some assembly tolerances occur, if you get any troubles or unsatisfied with it during the assembly, please follow the steps in the manual or contact us.

Thanks for your kind attention!


Parts List

A	B	C	D	E
				
Bottom Panel 1PC	Right Panel 1PC	Left Panel 1PC	Top Panel 1PC	Middle Panel:1PC 1PC
F	G	H	I	J
				
Leg 4PCS	Back Panel 2PCS	Handle 2PCS	Left Door 1PC	Right Door 1PC


HARDWARE LIST

#1	#2	#3	#4
			
Screw 28PCS	Shim 12PCS	8x35MM Bolt 12PCS	3x35MM Long Round Head Bolt 2PCS
#5	#6		
			
The Magnetic Closure 2PCS	Allen Wrench 1PC		

Step 1




Step 2




Step 3




Step 4




Step 5



Step 6



Step 7



**After step 7,
You may find,**

A big gap between the doors

Or

The doors are not aligned


Or

Doors are not leveled

**Don't worry. Don't feel frustrated.
Because your cabinet is a 100% handmade
decorative product, some assembly
tolerances occur.**

Please go ahead step 8,9,10

Step 8



Rotate & adjust legs slightly to make sure cabinet top and base is leveled.


If the cabinet top and base is not level, the result will be uneven cabinet doors. No matter that amount of adjustments, the doors will not be even.

Step 9

Step 10





Open the doors, loosen the #3 bolt a little bit, then close the doors.



Pat an wobble the sides of frame couple times until the doors are aligned and leveled. Then tighten the #3 bolts.

Step 11



**After doors are perfectly aligned,
assemble the back panel and tighten the
#1 screws.**

FINISH!

**Your cabinet is a 100% handmade decorative product,
some assembly tolerances occur, if you are unsatisfied
with the product, please contact us thru service mail,
and do not give us a low star rank online straight away.**

Thanks for your kind and mercy.

USE & CARE INSTRUCTIONS

KEEPING YOUR FURNITURE BEAUTIFUL

Quality furniture is a significant investment expected to last for years on end. To maintain its beauty & help it last, furniture needs the right care, as no finish is totally indestructible. However, with regular care, the finish will last much longer, providing years of enjoyment to you.

TIPS TO PROTECT & CARE FOR YOUR FURNITURE

1. Avoid placing your furniture in direct sunlight, as sunlight causes fading.
2. Avoid extreme changes in temperature by arranging furniture away from radiators, heat & air vents & air conditioning units.
3. Avoid placing plastic or rubber materials (lamp bases, notebooks, placemats, etc.) on your furniture, as certain plastics contain ingredients that may damage the finish.
4. Periodically rotate accessories on furniture, do not sit in the same place all the time.
5. Use pads, cloth or felt to protect the furniture surface from plastic, rubber, hot dishes beverages, bookends, flowerpots & vases.
6. Clean up spills immediately, using a blotting rather than wiping action, as water left over a long time will cause white spots in the finish. Alcohol, perfume, after-shave & medications can cause severe finish damage.
7. Use a protective pad when writing on the furniture surface.
8. Lift & place objects rather than dragging them across the furniture surface.
9. Avoid placing furniture directly under windows.
10. Use cutting boards and trivets for food preparation in order to avoid damaging the top of the furniture

WOOD FURNITURE CARE

We recommend dusting frequently with a clean, soft, dry, lint-free cloth. Wipe spills immediately with a clean cloth. Clean the surface by rubbing follow the direction of the grain and wipe dry. We recommend polishing your furniture approximately every six months. We do not recommend use aerosol-powered cleaners, polishes that contain silicone, waxes, abrasives, or oil based.

LEATHER FURNITURE CARE

To prevent cracks and surface damage we recommend keeping away from high humidity and low temperature rooms. Do not place close to fire, stoves or heaters. Wipe spills immediately with clean non-abrasive cloth or sponge. For spots or stains, clean with mild detergent and warm water. Wring out excess water make cloth is damp before use. Rinse cloth in clear water and wring out, then wipe again to remove detergent residue. To prevent damage use a dry cloth to wipe excess moisture. Also, do not use chemical cleaners that contain bleach.

GRANITE CARE

Our granite is sealed. We recommend cleaning spills promptly. For daily cleaning, use warm water and a soft clean cloth. Granite cleaners also can used for deep cleaning. We do not recommend using abrasive cleaners, chemical solvents, strong detergents, cleaners with bleach or vinegar. Be sure to use trivets, coasters, placemats, or adhesive felt pads to help prevent scratches.

FAUX WOOD/MARBLE CARE

We recommend dusting frequently with a clean, soft, dry, lint-free cloth. Wipe spills immediately with a clean cloth. We do not recommend use aerosol-powered cleaners, polishes that contain silicone, waxes, abrasives, or oil-based. To avoid damaging the surface of the furniture, always use a cutting board when cutting food or other items on the surface.

Do not place hot items directly on the surface; always use pads or trivets to prevent damage.

METAL FURNITURE CARE

Because most metals, except aluminum, are subject to rust, metal furniture is usually finished with layers of clear varnish, paint, or a durable powder coating. To clean, use a mild soap solution, scrub, rinse and dry. For outdoor furniture, make sure to drain any water that may accumulate inside the frames after rinsing. After cleaning, apply a coat of quality liquid or paste wax with a lint-free cloth. Use a silicone spray to lubricate swivels and glides on chairs. If metal outdoor furniture is caught during a sudden rainstorm, please make sure to drain any water that may have accumulated inside the frame and dry completely. **Please always cover the furniture when not use, and store properly during inclement weather and the winter/rainy seasons.** For indoor furniture, do not use abrasives products as this may lead to the accidental removal of antique finishes, also to staining or damage to surrounding areas of fabric.

FABRIC MATERIALS CARE

Prevent stains by removing crumbs, dust, dirt, and debris. To remove dirt and debris, vacuum with a dust-brush attachment. Clean spills immediately! For Linen – If the linen item is removable, place the item in a clean sink or tub with cool water and a mild detergent. Gently agitate the linen items, then remove from the soapy water. Rinse with cool water and hang dry. If not removable, then spot clean by dabbing with solution of cool water and a mild detergent on a soft nonabrasive cloth. For Microfiber - If the microfiber item is removable, use machine-wash them in cold water with mild detergent. No fabric softeners as they will clog the open spaces in the microfiber, making the fabric useless. Avoid washing the cotton items because the microfiber will grab on to the lint. If not removable, then spray the area lightly with a water-based solution; using a soft cloth and a blotting motion to remove the stain. Fully air dry.