




ASSEMBLY INSTRUCTION






Ax1


Bx1


Cx1


Dx1



Ex1


Fx1





Gx10
8X16



Hx12
M8X20


Ix10
M8X40



Jx1
5#


1






2





ASSEMBLY INSTRUCTION

3



4

