


Assembly Manual






Power Recliner with Power Headrest



CAUTION


THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Count parts before assembling.

A	1pc	B	1pc	C	1pc
					
Backrest		Seat		Left Wing	
D	1pc	E	1pc	F	2pc
					
Right Wing		Power Supply		Cupholder	


Step 1

Cut the plastic ties to remove the hardware pack (Includes: Power Supply (E) and Cupholders (F)). Locate the Left Wing (C) and Right Wing (D) at the bottom of the Seat (B), then take them out.




Step 2

Zip up the Backrest (A) and the Seat (B) together.




Step 3

Slide the Backrest (A) into the metallic quick connectors of the Seat (B). Push down the Backrest (A) firmly until each side is locked into place and an audible "click" is heard.



Step 4


Slide the the Left Wing (C) and Right Wing (D) into the Backrest (A).



Step 5


Connect the Wire (I) from the Backrest (A) to the corresponding Wire (H) on the base of the Seat (B).

Locate the Power Supply (E) and connect to its corresponding Receiver (G) on the base of the Seat (B).




Step 6

Attach the back cover to the bottom of the seat with velcro.



Step 7

Plug the Power Supply (E) into the power outlet.



Step 8

Pull it out and place the cupholders inside.

