
Shelf Floor Lamp User Manual


Assembly Steps

❶ Assemble the Bottom Board




(1) Holding **Bottom Board(A)** upside-down, insert 4 **Screws(F)** through each of the 4 coner holes.
(2) Insert 4 **Poles(D)** onto the exposed part of 4 serews and tighten with hex wrench.
So the screwheads are recessed into the four coner holes on the Bottom Board.

❷ Assemble 2 Shelves




(1)Place **Shelf(B)** onto the poles with holes aligned and screw the 4 **Bolts(G)** into each of 4 corners.
(2)Screw 4 **Poles(D)** onto the protruding bolts tightly.
(3)Install in sequence according to the previous method.

❸ Assemble Top Board




(1)Placing the **Top Board(C)** onto the 4 poles with holes aligned.
(2)Insert 4 **Screws(F)** through holes in the 4 corners and tighten with hex wrench so that the screwheads are recessed into the 4 corner holes on the Top Board.

Assembly Steps




❹ Assemble the Lamp Shade and Socket



(1)Unfold **Lamp Shade(J)** and Force the **Metal Shade Frame(I)** into clips that attached to the inside of the shade.
(2)Place the lamp shade onto top board.
(3)Insert the **Socket(E)** into the middle hole of top board and secure with wingnut underneath.


❺ Install Light Bulb and Secure the Wire




(l)Screw the light bulb into socket.
(2)Use **Clip(H)** to secure the wire on the pole.

TECHNICAL DETAILS

Lamp	
Model	PFL-007
Material	Wood + Metal + Linen
Voltage	100-120V
Power for Bulb	MAX 60W
Power Source	Corded-electric
Plug Type	US Plug
Base Type	E26
Switch	Pull Chain
Shade Color	White
Wire Length	300CM





Bulb	
Type	A19
Voltage	100-120V
Power	9W
Brightness	800LM
CCT	3000K/6500K/4000K
Life	25000+ Hours

Change CCT every 2 pulls

IMPORTANT SAFETY INSTRUCTIONS

1. To reduce the risk of electric shock, his lamp has apolarized plug (one blade is wider than the other). The plug will fit in a polarized outlet only one way.
   lf the plug does not fit fully into the outlet reverse the plug, If plug still does not fit, contact a qualified electrician,
   Never use an extension cord unless the plug can be fully inserted, Do not alter the plug.
2. Do not instal non-factory wiring or any other electrical components, Altering or modifying the lamp in any way will render the product unsafe.
3. Avoid laying objects directly over the power supply cord to prevent damaging or cutting the wire.
4. Keep curtains, shades, wall hangings and all other fabrics and obiects away from the lamp shade, light switch and the light bulb.
5. Place the lamp on a stable,level surface in a location where the lamp will not be tipped over or bumped. Do not hang obiects ftom the lamp shade or light switch
6.This lamp is approved for indoor use only.
7.ltems displayed on the lamp shelves should be non-flammable.

BULB REPLACEMENT

Use one 60 Wat maximum Type A bulb or CFL bulb equivalent. **DO NOT EXCEED RECOMMENDED BULB WATTAGE**.
Do not use a halogen bulb. Halogen bulbs operate at a higher temperature and pose a fire hazard.
1.Turn off and unplug the lamp before replacing the bulb.
2.Light bulb should never touch the shade.

CLEANING AND MAINTENANCE:

1 .Clean using a mild cleaning solution and soft cloth
2.Never use a rough cloth or chemical cleaners containing acids, abrasives or solvents.