Cat House

ASSEMBLY INSTRUCTIONS




14
15
16
18
17
19
17
1
4
7
10
11
2
5
8
12
3
6
9
13
20
20
20
20
21
21
22
22
22
23
23
23
23
23
23


42
41
26
27
28
24
39
37
32
34
40
31
29
25
35
38
33
30
36
43
43

1 x1 	4 x1 	5 x1 	6 x1 
8 x1 	10 x1 	11 x1 	12 x1 
13 x1 	14 x1	15 x1	18 x1
19 x1 	23 x4	32 x1 	33 x1 
34 x1 	35 x1 	36 x1 	

2 x1 	3 x1 	7 x1	9 x1 
16 x1	17 x2 	20 x4	21 x2
22 x3	23 x2	24 x1 	25 x1 
26 x1	27 x1	28 x1	29 x1
30 x1	31 x1	37 x1 	38 x1 

39 x1 	40 x1 	41 x1 	42 x1 
43 x2 			

A		M3.5x45mm	51PCS
B		M3.5x35mm	82PCS
C		M3.5x30mm	13PCS
D		M3.5x20mm	16PCS
E		M3.5x16mm	72PCS
F		M3.5x12mm	4PCS
G			2PCS
H			2PCS
I			3PCS
J			18PCS
K			3PCS
L			1PC

STEP 1



Bx2

STEP 2



Bx2

STEP 3



Bx2

STEP 4



Bx2

STEP 5



Cx3

STEP 6



Bx3

STEP 7



Dx2

STEP 8



Dx2

STEP 9



	Bx4

STEP 10



	Bx4

STEP 11

The interior of the third floor of the cat house contains insulation materials, providing a warm and comfortable environment for the cat in winter.



	Bx6

STEP 12



	Bx2

STEP13



	Bx4

STEP 14



	Jx6
	Ex12

STEP 15



	Jx8
	Ex16

STEP 16



	Ax3
	Bx8

STEP 17



STEP 18



STEP 19



Bx4

STEP 20



Ax3

STEP 21



STEP 22



 Bx4

STEP 23



 Cx10

STEP 24



Fx4

STEP 25



	Gx1
	Ax2

STEP 26



	Ax6

STEP 27



	Bx8

STEP 28



	Dx8

STEP 29



	Kx2
	Ex4

STEP 30



	Gx1
	Ax2

STEP 31



	Ax6

STEP 32



	Bx4

STEP 33



	Kx1
	Ex2
	Dx4

STEP 34



	Ax2

STEP 35



	Ax6

STEP 36



	Ax4

STEP 37



E x 4

STEP 38



A x 6

STEP 39



A x 6

STEP 40



B x 1