

Foot Fitting Instructions:

LAWSON


Foot A:



**PLEASE REMOVE
ALL TRANSIT FEET
BEFORE INSTALLING
DISPLAY FEET**

Armchair / Lovechair / 2 Seater / 3 Seater

Sofa Back:



Sofa Front:

PLEASE NOTE:

There are no pre-drilled holes. Place feet approx 0.5-1cm from the edge of the sofa and fix using the wood screws provided.