

EZL2439A(hera

80g双胶纸+四色印刷

说明书

100*490mm









页面顺序：

封面：01

正面内容：

页面顺序：

反面内容：

Brand Message Dear Customer, 10 years ago, EZVALO began with a simple idea: lighting our homes should be easy. At the time, traditional lighting required complicated, often unsafe wiring. The alternatives such as disposable battery lights or short-lived rechargeable lamps, were either environmentally unfriendly or unreliable. We knew there had to be a better way. So we founded EZVALO. Our name combines "EZ" (for "easy") and "VALO" (the Finnish word for "light"), expressing our mission: "Illuminate Every Corner." From cabinet lights that make kitchen tasks easier, to closet lights that help you find your clothes, to showcase displays, ceiling spotlights, and even outdoor landscape lighting, EZVALO brings light exactly where you need it. With over 10 million lights sold worldwide, we continue to innovate in battery life, motion sensing, and optical design. Our goal remains the same: to create efficient, long-lasting, and beautifully simple lighting that enhances everyday life. Thank you for being part of our journey. Warm regards, EZVALO Team	Safety Precautions  Carefully read and follow all the safety instructions. • Inspect the product and cable before use; contact support if damaged. • Keep packaging away from children and pets (choking hazard); the device is not a toy and requires adult supervision. • The Lithium-ion battery is non-removable; do not repair, disassemble, or modify. • If odor, overheating, or swelling occurs, turn off and unplug immediately. Contact our support. • Avoid heat sources and strong air currents, and high-moisture areas. Do not operate or store above 104°F (40°C); charge the battery only between 32°F (0°C) and 104°F (40°C). • For indoor use only; avoid water exposure as it is not waterproof. • Do not puncture, crush, incinerate, or place near combustible materials. • The LED is integrated and not replaceable. • All rechargeable batteries degrade over time; diminished capacity is normal for lithium-ion batteries. • Charge promptly when the light dims; recharge at least every 3 months if unused.	Customer Service  We stand behind our products 100% and guarantee to provide you with a satisfactory solution. 24-Hour Support: Need help? If there are quality issues, malfunctions, or missing accessories with the product, contact us! We'll respond within 24 hours. ✉ service@ezvalo.com 30-Day Returns: Not satisfied? Return unused items within 30 days of purchase for a refund or exchange. 2-Year Warranty: Your product is covered for defects in materials or workmanship under normal household use for 2 years from purchase. If it malfunctions during this warranty, we provide a free replacement with covered shipping.	Installation ➊ Rotate the bracket clockwise to connect it to the base.  ➋ For a perfect parallel angle, don't force the hose if it still looks crooked after tightening. Just rotate the bracket counter-clockwise slightly until it's aligned.  ➌ Drill holes on the wall (according to the distance of the holes on the bracket).  ➍ Install plastic expansion screws and secure the bracket with metal screws. Tip: For drywall and cement wall, use included anchors.  ➎ After turning the light to ON, align it with the ▲ mark on the light and bracket to install the light.  ➏ Adjust the bracket hose to obtain the optimal illumination angle. 	Remote Control ON button ● Brightness + ● OFF button ● Timer buttons ●  ●Brightness - ●White Light buttons <table><tr><th>Button</th><th>Instructions</th></tr><tr><td>ON/OFF button</td><td>Press to power the lamp on/off</td></tr><tr><td>Brightness +/-</td><td>Press to increase/decrease the brightness</td></tr><tr><td>White Light buttons</td><td>Press to switch the light color: Cool White / Natural White / Warm White</td></tr><tr><td>Timer buttons</td><td>Press to set a 15/30/60/120-minute timer and keep the light on. Press Cancel to abort.</td></tr></table>	Button	Instructions	ON/OFF button	Press to power the lamp on/off	Brightness +/-	Press to increase/decrease the brightness	White Light buttons	Press to switch the light color: Cool White / Natural White / Warm White	Timer buttons	Press to set a 15/30/60/120-minute timer and keep the light on. Press Cancel to abort.	▲ Note  ➊ Before use, please pull out the insulating tab.  ➋ Set the toggle switch to ON before use, or the remote will not work.  ➌ Point the remote directly at the front of the fixture for optimal range and reliability.  ➍ Replace the battery; remove the screw with a screwdriver, press the tab on the side of the battery cover to slide it out, then insert a CR2025 battery with the (+) side facing up.
Button	Instructions														
ON/OFF button	Press to power the lamp on/off														
Brightness +/-	Press to increase/decrease the brightness														
White Light buttons	Press to switch the light color: Cool White / Natural White / Warm White														
Timer buttons	Press to set a 15/30/60/120-minute timer and keep the light on. Press Cancel to abort.														
1	2	3	4	5	6	7									