









Assembly Instruction


Thank you for your purchase. Before discarding packaging material be sure you have located all the parts including the necessary hardware and tools listed on the instruction sheet below.

*****Caution:** Read before unpacking Assembly Parts. Sharp exposed staple tips can cause injury. For your protection, please remove any exposed staples used in packaging.

NO.	PARTS LIST		Q'TY
A		Top frame	1pc
B		Legs	4pcs
C		Shelf	1pc


NO.	HARDWARE LIST		Q'TY
1		Allen Key M4	1pc
2		Bolt Ø1/4" x 2"L	8pcs
3		Spring Washer Ø1/4"	8pcs
4		Flat Washer Ø1/4"	8pcs
5		Screws 8#	4pcs
6		Not provided	

Step 1




1. Lay top assembly upside down on a flat, soft surface such as a carpet or a cloth to prevent scratching the table finish. Attach four legs to the aprons by using Flat Washers (4), Spring Washers (3), Bolts (2) and Allen Key (1). Note: Do not tighten the bolts on this step.

Step 2




2. Attach the Shelf (C) to the Legs (B) by using Phillips head screw driver (not included) to tighten the screws (5). Note: Do not tighten the bolts on this step. Tighten all the Bolts securely.

Step 3



3. Use a screwdriver (Not provided) to remove the hardware.

Step 4



4. Place the knob to the drawer front. Assembly is now complete.

Thank You For Your Purchase