
TV STAND

Assembly Instructions - Please keep for future reference



Dimensions

Width-66.93inch
Depth-14.56inch
Height-23.62inch

Important - Please read these instructions fully before starting assembly

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts

• Regularly check and ensure That all bolts and fittings are tightened properly.

WARNING
In order to help prevent overturning – please follow these instructions








To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


Components-Fittings

Please check you have all the panels llsted below

Note:The quantlle below are the correcet amount to complete the assembly. in some cases more fittings may be supplied than are required.

Ⓐ  6*35mm Cam Bolt x 6	Ⓑ  15*10mm Cam Lock x 6	Ⓒ  8*30mm Dowel x 26+2	Ⓓ  4*40mm Screw x 16+2
Ⓔ  3.5*12mm Screw x 64+2	Ⓕ  Hinge x 4	Ⓖ  Phillips screwdriver x 1	Ⓗ  4*20mm Screw x 12+2
Ⓘ  35*25*5mm EVA x 8	Ⓙ  Back plate buckle x 16+2	Ⓚ  Shelf bracket x 8	Ⓛ  Allen key x 1
Ⓜ  M6*55mm Screw x 14+2	Ⓝ  Hinge x 4	Ⓞ  Hole to stick x 6	Ⓟ  Prevent rewinding x 2
Ⓠ  3.5*14mm Screw x 2	Ⓡ  Expanded plastic x 2		

Tools required




Phillips screwdriver or
flat-head screwdriver

Using Camlocks


Step 1

Connect the male camlock as diected in the assembly instructions using a scewdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instruction.

Note：ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4


Turn the female camlock clockwise with a screwdriver.












You should feel a click when the camlock is locked in place.

The joint is now secure.




Assembly Instructions




 1670*340*15mm	 1670*340*15mm	 510*339*15mm	 510*339*15mm
① X1	② X1	③ X1	④ X1
 510*339*15mm	 635.5*297*15mm	 1326*76*18mm	 1326*76*18mm
⑤ X1	⑥ X2	⑦ X1	⑧ X1
 550*328*18mm	 550*30*18mm	 1210*50*25mm	 647.5*259*3mm
⑨ X4	⑩ X4	⑪ X2	⑫ X4
 550*550*16mm	 310*200*50mm	 638*19*6mm	
⑬ X2	⑭ X2	⑮ X2	

Assembly Instructions


Step 1




Ⓐ	Ⓒ
	
6*35mm Cam Bolt x 6	8*30mm Dowel x 6


Step 2

Step 1 Step 2 Step 3






Ⓑ	Ⓞ
	
15*10mm Cam lock x 6	Hole to stick x 6




Assembly Instructions

Step 3




Step 4




© 8*30mm Dowel x 6

Assembly Instructions

Step 5




Ⓓ



4*40mm Screw x 6

Step 6




Ⓒ



8*30mm Dowel x 6

Assembly Instructions

Step 7



M




M6*55mm Screw x 14

L



Allen key x 1

Step 8



J



Back plate buckle x 16

I



35*25*5mm EVA x 8


E




3.5*12mm Screw x 16

Assembly Instructions

Step 9



Caution Notice
At least two people need to complete it simultaneously.




Ⓒ




8*30mm Dowel x 8

Step 10




Ⓓ




4*40mm Screw x 8

Assembly Instructions

Step 11




Align the Velcro on Plate 13 with the Velcro on Plates 1 and 2, and attach it in the direction of the arrows as shown in the diagram.



After assembly is completed, please avoid repeatedly removing Part13 to prevent it from becoming loose or detaching.

Assembly Instructions

Step 12




Ⓚ



Shelf bracket x 8


Step 13



Assembly Instructions

Step 14

The following steps are for installing the hinge N




X 2

Ⓔ	Ⓝ	Ⓗ
3.5*12mm Screw x 8	Hinge x 4	4*20mm Screw x 6

Step 15

The following steps are for installing the hinge N




Ⓔ
3.5*12mm Screw x 8

Assembly Instructions

Step 16

The following steps are for installing the hinge N




Ⓔ


3.5*12mm Screw x 8

Step 17

The following steps are for installing the hinge F




X 2

Ⓔ	Ⓕ	Ⓗ
		
3.5*12mm Screw x 8	Hinge x 4	4*20mm Screw x 6

Assembly Instructions

Step 18




The following steps are for installing the hinge F

Ⓔ



3.5*12mm Screw x 8

Step 19



The following steps are for installing the hinge F


Ⓔ




3.5*12mm Screw x 8


Assembly Instructions

When the hinges are installed, you can refer to the pictures to adjust the screws of the doors till it's perfect.





1. Adjust the screws shown in Fiqure 1 to adjust the door up and down.







2. Adiust the screws shown in Fiqure 2 to adjust the door left and right to the right position.





3. Adjust the screws shown in Fiqure 3 and pull the door back and forth so that it can be opened smoothly.






4. After the adjustment is complete, secure the remaining two screws to secure the door in place.

Assembly Instructions

Step 20




Ⓠ




3.5*14mm Screw x 2

Ⓟ



Prevent rewinding x 2

Step 21




Ⓡ



Expanded plastic x 2

Ⓓ



4*40mm Screw x 2

Assembly Instructions

FINISH

