



# How to Adjust Euro Hinges



**3 Turn the innermost screw to shift the door horizontally.** Rotate the hinge screw closest to the door. Turning it clockwise moves the door closer toward the far side of the cabinet frame. Turning it counterclockwise moves the door back toward the hinge. Keep making minor adjustments to center the door on the frame and reduce any gaps between adjacent doors.<sup>[5]</sup>

- For example, adjust the screw to move the door over. Leave a 1 to 2 mm (0.039 to 0.079 in) gap between this door and the next one.
- If the door isn't hanging straight, adjust the top and bottom hinges in different directions.



**4 Close the cabinet doors after each adjustment to check your progress.** Make gradual corrections to avoid throwing the doors out of alignment. After turning the hinge screws, shut the door, take a step back, and check the door's positioning. Open it back up if you need to make further adjustments.<sup>[6]</sup>

- Although shutting the door so often can seem tedious, it helps prevent the door from moving too much. Take it one adjustment at a time so you don't end up needing to make big corrections later.

<https://www.youtube.com/watch?v=56cqwMnKRz0>