

ASSEMBLY INSTRUCTIONS FOR DINING TABLE

FIGURE 1



1 Turn Dining Table top upside on a soft and even surface as in Figure 1.

2 Unscrew the BOLT and washer from legs with the help of spanner (1 pc) provided ; attach the leg marked 'No.' to base marked 'No.' so on as in figure 2.

FIGURE 2



3 Fix and tighten washer and bolts to the BASE with the help of spanner as in figure 3.

4 Tighten to ensure no play in legs assembled . Now turn Dining Table in upright position as in figure 4.

FIGURE 3



Now your Dining Table is Ready to use.

Care and Maintenance

1 For General cleaning use a dry cloth do not use wet cloth, soap, detergent, aerosol sprays and polish on the product.

2 Do not place hot or cold items directly on the surface. Use of placemat is recommended to avoid marks.

3 This product is manufactured in solid hardwood and is made for indoor use.

FIGURE 4

