











Assembly Instruction

Thank you for your purchase. Before discarding packaging material be sure you have located all the parts including the necessary hardware and tools listed on the instruction sheet below.
Caution: Read before unpacking Assembly Parts. Sharp exposed staple tips can cause injury. For your protection, please remove any exposed staples used in packaging.

PARTS LIST

NO	DESCRIPTION	FIGURE	QTY
1	Cabinet Top		1pc
2	Feet		6pcs
3	Acrylic Pull		4pcs

HARDWARE LIST

NO	DESCRIPTION	FIGURE	QTY
A	Bolt		12 pcs
B	Flat Washer		12 pcs
C	Spring Washer		12 pcs
D	Allen Key		1 pc
E	Flat Screw		8 pcs
F	Rubber Gasket		8 pcs
G	Copper Sleeve		8 pcs


INSTRUCTIONS:

STEP 1. Place pre-assembled cabinet (1) upside down on a soft, flat surface. Insert the feet (2) to pre-assembled cabinet(1), fully tighten all the feet.


STEP 2. Place the cabinet upright, install the acrylic pull into the door.

SEE THE ILLUSTRATION


STEP 1



STEP 2



STEP 3



Thank you for your purchase.

Assembly is completed