

ASSEMBLY INSTRUCTION

Caution : You must read this before you proceed


Care & Maintenance

- ⊘  • Not for commercial use. For residential use only.
- ✓  • Furniture may scratch floors. We recommend using furniture pads to protect your floors.
- ⊘  • Do not put hot items directly on furniture surface.
- ⊘  • Do not clean furniture with harsh cleansers or polish.
- ⊘  • Do not place furniture under direct sunlight.
- ⊘  • Do not place furniture near heating or cooling vents.
- ⊘  • Do not write on furniture without a padded barrier to protect the surface.
- ⊘  • Do not place furniture outside. For indoor use only.
- ⊘  • Stains may be removed with mild soap solution and damp cloth.
- ⊘  • Children should not climb or jump on the furniture.









- ✓  • Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in carton for hardware packs and legs.
Sets often ship in multiple boxes and may arrive a day or two apart.



**DINING CHAIR
N768P489406**



Parts List


Label	Picture	Description	QTY
A		Backrest frame	1
B		Seat cushion	1
C		Right front leg	1
D		Right back leg	1
E		Left front leg	1
F		Left back leg	1
G		Front stretcher	1
H		Right stretcher	1
I		Left stretcher	1
J		Back stretcher	1

HARDWARE LIST


Label	Picture	Description	QTY
①		Bolt (1/4" x45mm)	14+1
②		Spring washer (10mm)	14+1
③		Flat washer (14 mm)	8+1
④		Crescent washer	6+1
⑤		Allen wrench	1+1
⑥		Dowel (Ø8x30mm)	10+1
⑦		Screw (4x50mm)	8+1
⑧		Levellers	2
⑨		Felt pad	2

Assembly Preparation

Before Beginning Assembly:



not included





- Read instructions, cover to cover-



- Have 2 adults on hand fo assembly-



- Do not assemble on flooring of carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-

Assembly Steps


Overview



This chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the chair parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarize yourself with the parts and steps before assembly.


CAUTION : When tightening these bolt, tighten sequentially.
DO NOT tighten any bolt fully and then towards the next one.
This would cause the frame to warp.
If there is still wobbles, loosen the bolt and execute this same process.
WARNING!! IF IT IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.

Step 1




Attach the front stretcher G to the left & right stretcher H&I. Using dowel ⑥, bolt ①, spring washer ②, crescent washer ④ and allen key ⑤. Fully tighten.

Step 2




Attach the back stretcher J to the left & right stretcher H&I. Using dowel ⑥, bolt ①, spring washer ②, flat washer ③ and allen key ⑤. Fully tighten

Step 3




Attach the seat cushion B to the stretcher frame. Using dowel ⑥, screws ⑦ and screwdriver Fully tighten.

Step 4




Attach the front stretcher G to the right front leg C. Using bolt ①, spring washer ②, crescent washer ④ and allen key ⑤. Do not full tighten

Step 5




Attach the back stretcher J to the right back leg D.
Using bolt ①, spring washer ②, crescent washer ④ and allen key ⑤. Do not full tighten

Step 6




Attach the back stretcher J to the left back leg F.
Using bolt ①, spring washer ②, crescent washer ④ and allen key ⑤. Do not full tighten

Step 7




Attach the front stretcher G to the left front leg E .
Using bolt ①, spring washer ②, crescent washer ④ and allen key ⑤. Do not full tighten

Step 8




Attach the all legs.
Using bolt ①, spring washer ②, flat washer ③ and allen wrench ⑤. Fully tighten.

Step 9



Attach the backrest frame A to the right front leg C and left front leg E. Using dowel ⑥, bolt ①, spring washer ②, flat washer ③ and allen key ⑤. Do not full tighten

Step 10



After checking the chair, if no problem, tighten all the bolts.

Stand the chair up .

Place the chair on a **LEVEL SURFACE** to check for wobbles .

If the chair wobbles, adjust the levellers ⑧ at the bottom of the front legs.

Note: If missing or fall out the felt pad on the rear legs, attach new one ⑨ .

Your chair is ready for use.