


ASSEMBLY INSTRUCTIONS



DESK RETURN

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

20 MINUTES


PARTS IDENTIFICATION

A TOP PANEL




1 PC

C RIGHT SIDE
PANEL




1 PC

B LEFT SIDE
PANEL



1 PC

D BACK PANEL



1 PC

Z

HARDWARE IDENTIFICATION

NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 15g		1 PC
2	CAM BOLT Ø 7x35.5mm SR		4 PCS
3	CAM LOCK Ø 15x12mm SR		4 PCS
4	ADJUSTMENT FEET Ø 35x17.2mm		4 PCS
5	COUPLER		5 PCS
6	BOLT Ø 4.5x12mm SR		5 PCS


NO	DESCRIPTION	FIGURE	Q'TY
7	BOLT Ø 6.2x45mm SR		4 PCS
8	BOLT Ø 6.2x18mm SR		1 PC
9	SCREW Ø 4.2x25.4mm RBW		10 PCS
10	WOODEN DOWEL Ø 8x30mm		4 PCS
11	STICKER Ø 20mm		1 PC

Z4,Z5 not included in blister packaging.


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


STEP 1




STEP 2




STEP 3




STEP 4



STEP 5





Note : Dimension tolerance $\pm 5\%$