


INSTRUCTION ANWEISUNG

取扱説明書

INSTRUCTION

사용설명서




A×4




B×4




C×4




D×8




E×4




F×4




G×16




H×16



I×8



J×32




K×64




L×40





M×40



N×1



O×1





FR
Ce meuble se recycle,
s'il n'est plus utilisable
déposez-le en déchèterie.
Notice à trier.

EC REP

UK REP



1

- J×2
- M×2
- L×2
- K×2
- G×2



2


- J×2
- G×2



3

 K×4

 H×4





4

 J×2

 M×2

 L×2


 K×4



5




- J×8
- M×8
- L×8



6




- J×8
- M×8
- L×8



7



- I×4
- M×4
- L×4
- K×8



8



- I×4
- M×4
- L×4
- K×8

