

# USER GUIDE



# LAUNDRY BASKET

# SAFETY & WARNINGS


## Warning

- Read each step carefully before starting.
- Remove all fittings from the plastic bags and separate them into their groups.
- Read these assembly instructions carefully, and keep them in a safe place!
- Never leave children unattended with the packaging materials. There is a risk of suffocation.
- It is important that each step is performed in correct order to avoid difficulties.
- Assemble the product on packaging cardboard to prevent scratch or damage.
- Using incompatible hardware might cause damage to the product.
- Do not let children climb on or play with the product.
- Handle with care.
- To avoid scratching the floor, assemble the product on a soft surface such as a carpet.
- Do not put heavy items on the product, this laundry sorter is only suitable for towels and clothes.
- Please use in clean and safe environment and keep it away from water, fire, high temperature and dirty place.

# INSTALLATION

## Step 1

Unpack all parts from the package and place them on a flat surface.




## Step 2

Connect the black plastic elbows to the both ends of the aluminium tubes. Sort out the long tubes and short tubes.



### Step 3

Insert the long tubes to the outside x-shaped bracket. Insert the short tubes to the inner side x-shaped bracket.



### Step 4

Fix the oxford cloth bag on the x-shaped bracket with velcro.



# CLEANING & CARE

- Clean the product with mild cleanser using soft dampened cloth. Do not use harsh or abrasive cleanser.
- Wipe with a dry cloth as needed to remove dust and dirt.
- Avoid contact with corrosive substances like acids, alkaline or similar substances.
- Dispose of the products and the packaging in an environmentally friendly manner.