



Reset Remote to Factory Settings

To reset the remote control to factory settings, press and hold the FLAT & ZG buttons together for about 5 seconds.