


Magnetic Floating globe

Thank you for purchasing this product!
To enjoy the product, please follow the instructions below.

OPERATION INSTRUCTIONS



- Connect the adaptor to the main electricity supply, and then Switch on the power.
- Place the device on a flat level surface. If the surface is not flat and level, the globe will not levitate.
- Place one finger on the top of the globe. Hold the bottom of the globe with your other hand.
- Position the globe 1/4 inch below the frame. This is the floating distance. When the globe is in the proper position, you will feel a strong force holding the globe. Release the globe gently.

CAUTIONS

- The globe should not be put near a computer or other electronic device due to its magnetic field.
- Do not drop the globe on a hard surface.
- **THIS IS NOT A TOY. NOT SUITABLE FOR CHILDREN UNDER 12 YEARS OLD.**
- **FOR INDOOR USE ONLY**


Package list

1pc C shape frame
1pc 3inches globe
1pc 12V 1000ma adapter
1pc Instructions

磁悬浮地球仪

感谢您购买本产品， 请按以下说明操作， 您将拥有充满魔力和惊奇的体验！

操作指导



- 请将产品放在一个平整的水平桌面上， 如桌面不水平， 地球仪将无法悬浮。
- 将电源适配器插入电源插座， 电源线的另一端子插入框架底部的DC孔。
- 接上电后产品会亮灯。
- 一只手扶着地球仪， 另外一只手把辅助悬浮装置(手柄)放在地球仪顶上（带有磁体的一端）。如图所示,慢慢接近支架顶部,并紧贴放手后,此悬浮物品已处于悬浮状态,慢慢抽出手柄,地球仪便能够悬浮起

注意事项

- 此产品有磁性， 请远离其他电子产品（例如电脑）至少20CM。
- 请不要将产品抛丢在坚硬的地面上， 否则掉下来会损坏地球仪里面的磁铁。
- 此产品非玩具， 不适合12岁以下的儿童使用。
- 只限室内使用。

包装清单

1. 架子一个 2. 悬浮地球仪一个 3. 电源一个 4. 使用说明书一张