


















ASSEMBLY INSTRUCTIONS








Detail View




Part List

1  Top Panel - 1pc	2  Bottom Panel - 1 pc	3  Side Panel (Left) - 1 pc
4  Side Panel (Right) - 1 pc	5  Top Panel (Small) - 1pc	6  Bottom Panel (Small) - 1pc
7  Right Panel (Center) - 1pc	8  Center Panel - 1pc	9  Left Panel (Center) - 1pc
10  Shelf - 1 pc	11  Door Panel (Left) - 1 pc	12  Door Panel (Center) - 1pc
13  Door Panel (Right) - 1 pc	14  Back Panel (Left) - 1 pc	15  Back Panel (Right) - 1 pc

Hardware List


A  Ø8*30mm Wood Dowel (24 pcs)	B  Ø8*50mm Wood Dowel (4 pcs)	C  Cam Nut (14 pcs)
D  Cam Bolt (14 pcs)	E  Ø4 x 45mm Chip Board Screw (10 pcs)	F  Ø3.5 x 16mm Chip Board Screw (72 pcs)
G  3/4" Nails (52 pcs)	H  Metal Plate (2 pcs)	I  5/8" Hydraulic Hinges (4 pcs)
J  2/8" Hydraulic Hinges (2 pcs)	K  Metal Leg (7 pcs)	L  Metal Handle (3 pcs)
M  M4 x 30 mm TMS Screw (6 pcs)		


ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)



PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE POSITION WHEN YOU USE POWER TOOLS !

STEP 1 :

A	B	D
		
8 PCS	4 PCS	14 PCS




STEP 2 :


A



16 PCS



STEP 3 :




STEP 4 :

C



2 PCS




STEP 5 :

C



10 PCS




STEP 6 :

C




2 PCS




STEP 7 :


E



10 PCS



STEP 8 :




G




52 PCS

STEP 9 :



H




2 PCS

F



36 PCS


K




7 PCS

REMARK!
SECURE BOTTOM PANELS WITH METAL PLATES

STEP 10 :



STEP 11 :




STEP 12 :


F





24 PCS




Use the "waist round hole" marked with a triangle to adjust the position of the door panel (ensure that the gap between the door panel and the upper and lower panels is consistent).



Use the screw at the back end of the hinge to adjust the front and back position of the door panel (ensure that the front of the door panel is in the same plane as the upper and lower panels).



Use the screw at the front end of the hinge to adjust the left and right position of the door panel (ensure that the left and right sides of the door panel are in the same plane as the upper and lower panels).



After completing these three steps, secure the other two screws on the hinge.

STEP 13 :

