




COFFEE TABLE ASSEMBLY INSTRUCTION


Coffee Table




Parts & Hardwares




Step 1: Lay the Table Top(①) upside down onto a clean smooth surface such as carpet or cardboard. Align and fix two Top Rails(④) to the Table Top(①) with screw(B) by Allen Key(D). Do not fully tighten all bolts until all parts are in place.



Step 2: Attach and fix two Table Legs(③) to the assembled Top Rail(④) by using screw(A) with supplied Allen Key(D). Align these two Bottom Rails(⑤) to the assembled Table Leg(③) by screw(A) and tighten with supplied Allen Key (D). Do not fully tighten all bolts until all parts are in place.



Step 3: Put the assembled Table top on its side as shown. Attach and fix the Shelf(②) to the assembled Bottom Rails(⑤) with screw(C) by Allen Key(D). With the help of another person flip the desk upright.



COFFEE TABLE ASSEMBLY INSTRUCTION

Thank you for purchasing our coffee table. If any part from our order is missing or damaged, please email us for replacement. You can find us and get the product support quickly.

PRE-ASSEMBLY:

- (1) Proper assembly of this item requires 2 people.
- (2) Do not dispose of any contents until assembly is completed to avoid accidentally discarding small parts or hardware.
- (3) Remove all parts and hardware from box and lay out on a carpeted or scratch-free work surface, such as the shipping box, as this will avoid damaging any parts during assembly.
- (4) Do not fully tighten all bolts until all parts are in place. Failure to follow these instructions may cause the bolts to misalign during assembly.

CARE INSTRUCTIONS:

- (1) Hardware may loosen over time. Periodically check that all connections are tight.
- (2) Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.
- (3) All hot serving dishes should be placed on a pad.
- (4) Any liquid spilled onto the furniture should be cleaned up immediately with a damp cloth.