



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

108541 (B1&B2)
Dining Table

ITEM: 108541(B1&B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A TOP



1PC

B LEAF



2PCS

C APRON




2PCS

D CROSSBAR



1PC


E MIDDLE CROSSBAR



2PCS

B2 (BOX 2)

F LEG FRAME



2PCS

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 108541(B1)

1 SHORT BOLT
(Ø5/16" x 1-1/2" - RBW)



12PCS

2 LONG BOLT
(Ø5/16" x 2" - RBW)



4PCS

3 THREADED BOLT
(Ø5/16" x 3" - RBW)



4PCS

4 LOCK WASHER
(Ø5/16" - RBW)



16PCS

5 FLAT WASHER
(Ø5/16" - RBW)



16PCS

6 HEX NUT
(Ø5/16" - RBW)



4PCS

7 HALF ROUND NUT
(Ø5/16" - RBW)



4PCS

8 ALLEN WRENCH
(4MM - RBW)



1PC

9 WRENCH
(RBW)




1PC

ITEM: **108541(B1&B2)**


ASSEMBLY INSTRUCTIONS




STEP 1



STEP 2



STEP 3




ITEM: **108541(B1&B2)**


ASSEMBLY INSTRUCTIONS



STEP 4




STEP 5




ITEM: **108541(B1&B2)**

ASSEMBLY INSTRUCTIONS


STEP 6



STEP 7 COMPLETE



ITEM: **108541(B1&B2)**



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

108545BLK
Sideboard

ITEM: 108545BLK

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A **SIDEBOARD**



1PC

B **LEG FRAME**



2PCS

C **CENTER SUPPORT LEG WITH LEVELER**



1PC

HARDWARE IDENTIFICATION

1 **BOLT**
(Ø5/16" x 1-1/2" - RBW)



6PCS

2 **LOCK WASHER**
(Ø5/16" - RBW)




6PCS

3 **FLAT WASHER**
(Ø5/16" - RBW)



6PCS

4 **ALLEN WRENCH**
(4MM - RBW)




1PC


ITEM: **108545BLK**
ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2



ITEM: **108545BLK**
ASSEMBLY INSTRUCTIONS




STEP 3







NOTE: Please only open one door of the sideboard when using it.

STEP 4
COMPLETE



OPTIONAL ADJUSTABLE SHELF



NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **108545BLK**

ANTI-TIPPING INSTALLATION INSTRUCTIONS



FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.



This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.


This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
2. Determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
4. Attach the bracket over the plastic wall anchor using the long screw.
5. Place the unit against the wall, both brackets need to be facing each other.
6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
7. Ensure that the restraint strap is securely laced and locked.



ITEM: **108545BLK**



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

108546BLK
Side Chair

ITEM: 108546BLK

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	SEAT AND BACK		1PC
B	LEFT LEG FRAME		1PC
C	RIGHT LEG FRAME		1PC
D	MIDDLE STRETCHER		1PC

HARDWARE IDENTIFICATION

1	BOLT (Ø1/4" x 1-1/2" - RBW)		4PCS
2	LOCK WASHER (Ø1/4" - RBW)		4PCS
3	FLAT WASHER (Ø1/4" - RBW)		4PCS
4	ALLEN WRENCH (4MM - RBW)		1PC
5	PAN HEAD SCREW (#8MM x 1" - RBW)		2PCS

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **108546BLK**
ASSEMBLY INSTRUCTIONS




STEP 1



STEP 2
COMPLETE



ITEM: **108546BLK**



Note: Dimension tolerance $\pm 5\%$