





We recommend using hand tools for assembly.
If an electric screwdriver is used, reduce power and torque to avoid damage to the product.




AVOID SCRATCHES

In order to avoid scratching, this furniture should be assembled on a soft surface, such as a rug.
















⚠ Caution




Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.

Parts List



1  1 pc	2  2 pcs	3  2 pcs	4  2 pcs
5  1 pc			


Hardware List


A	B	C	D	E	F
					
M6x40mm	M6x65mm	M4	Ø44	Ø22	M14
4 pcs	4 pcs	1 pc	8 pcs	8 pcs	1 pc


G	H	I	J	K	
					
Ø8x30mm	M8x75mm	M8	M8	M8	
4 pcs	8 pcs	8 pcs	8 pcs	8 pcs	


1


G	H
	
Ø8x30mm	M8x75mm
4 pcs	8 pcs




















2


I	J	K	F
			
M8	M8	M8	M14
8 pcs	8 pcs	8 pcs	1 pc






3


A	B	C
		
M6x40mm	M6x65mm	M4
4 pcs	4 pcs	1 pc







4


D	E
	
Ø44	Ø22
8 pcs	8 pcs








Thank you for your support!





When it is not level on the ground, please adjust here.