




# Extra Large Premium Plus A-Frame Doghouse


## Assembly Instructions

Item #01708

#30001708




**Step 1** Connect the Front Panel and the Back Panel to the Left Side Panel and right Side Panel using the 8 - 2 3/8" Nuts and Bolts (A).




**Step 2** Insert the two piece floor panel into the assembled doghouse


**Tip: The corners of the floor panels are notched to fit the outside corners**



**Step 3** Attach the two piece Shingle Roof Panels to the assembled doghouse using the 8 - 1 1/4" screws (B).



**Step 4** Place the Ridge Cap onto the Shingle Roof Panels and secure using 4 - 1" screws (C). Attach 3 star shaped bolts (D) on the doghouse door frame in the threaded holes.



### Ware Tip

Your Premium<sup>+</sup> Doghouse has four adjustable feet, designed to allow you to level your doghouse

### Care Tip

To protect the wood on your doghouse you need to re-apply the protective stain finish at least 1x each year. Use a safe and non-toxic water based stain (available at your local paint or hardware center). Keep doghouse in a safe area away from high winds and extreme temperatures.

If you have any questions or concerns about this product, contact our customer service department at 1-800-295-2243 or [cs@waremfginc.com](mailto:cs@waremfginc.com) and we will help you with any problems, Mon-Fri 8:00 – 4:00 MST