

*ASSEMBLY INSTRUCTIONS*  
*COASTER FINE FURNITURE*



*WRITING DESK*

# ASSEMBLY INSTRUCTIONS


## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.








## WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.







ASSEMBLY TIME 30 MINUTES

## PARTS IDENTIFICATION

A	TOP GLASS		1PC
B	FRONT PANEL		1PC
C	BACK PANEL		1PC
D	LARGE CROSSBAR		2PCS
E	SMALL CROSSBAR		2PCS


## HARDWARE IDENTIFICATION

1	BOLT (1/4" x 18mm SR)		12PCS	3	SUCTION CUP (16.5 x 9.2mm)		6PCS
2	CAP (15 x 60mm BLK)		4PCS	4	ALLEN WRENCH (4mm)		4PCS


# ASSEMBLY INSTRUCTIONS

## STEP 1



Do not tighten until each step is completed or instructed.



## STEP 2




COMPLETE



# ASSEMBLY INSTRUCTIONS

**Product Size : 1200 X 597 X 762 H (MM)**

**Product Size : 47.25" X 23.5" X 30"**



Note : Dimension tolerance  $\pm 5\%$