











ASSEMBLY INSTRUCTIONS



Storage Cabinets Type D




Part List


①	②	③	⑥	⑧
				
x1	x1	x1	M3x28 x2	M4x14 x2

A	B	C	E1	E2	F	G	H1
							
x4	x1	x2	Long x6	Short x14	x1	x4	x4



H2	J1	J2	M	N	II
					
x4	x2	x2	x40	x1	x1

W

x2

Step1




Step2




Mx14
Step2x2

Step3	Step4 Ax2
Step5 Partially unscrew the three screws in ① before installing it on the metal panel. Cx1 ①x1 Step5x1	Step6 Partially unscrew the three screws in ② before installing it on the metal panel. Cx1 ②x1 Step6x1
Step7 Step5x1 Step6x1	Step8 Ax2


Step9




Step10




Step11




How to use the lock



Turn clockwise to unlock



Turn counterclockwise to lock



Including 2 keys