



# ASSEMBLY INSTRUCTION

## DESCRIPTION: TV CONSOLE

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts List Below:



OPTIONAL ANTIQUE  
MIRRORED GLASS



OPTIONAL  
WOOD DOOR


### PART LIST:

①		②	
TV STAND: 1PC		WOOD PANEL: 4PCS	

### HARDWARE LIST

NO.	Drawing	Description	Q'ty
A		Furniture Tipping Restraint	1 Set

1. Remove wood panel from inner box




## CLEANING INSTRUCTION

Clean the TV Console surface with a furniture polish and a soft cloth.


# ASSEMBLY INSTRUCTION

DESCRIPTION: TV CONSOLE


## OPTIONAL WOOD PANEL




**STEP 1:** Open the door back panel




**STEP 2:** Remove antique mirrored glass



**STEP 3:** Insert wood panel



**STEP 4:** Attach the door back panel with decorative screw



## CLEANING INSTRUCTION

Clean the TV Console surface with a furniture polish and a soft cloth.