


Spare Parts (Under sofa)



①	②	③	④	⑤	⑥	⑦
BACK CUSHION (2PCS)	ARM (2PCS)	SOFA BACK (1PC)	SEAT FRAME (1PC)	LEGS 2PCS OF FRONT LEG 2PCS OF BACK LEGS	HARDWARE (1 BOX)	THROW PILLOWS (2PCS)

Important:

After taking out the back cushions from the arms, open the package carefully. Then "HAVE TO" Slap and knead the cushions around powerfully by hands, to make the cushions loose and fluffy.

