


ASSEMBLY INSTRUCTION



WARRANTY:

We stand behind our products & service with confidence! If parts damaged or missing please feel free to contact us for a FREE REPLACEMENT.

We warranty this product to be free from defects in materials. This warranty covers one year from the date of original purchase.

NOTES:








- The item is only intended to be used indoors. The product must be assembled and used in accordance with the provisions of the manual.
- It is recommended that assembly is undertaken by about 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outlined. Estimated assembly time is 30 minutes.

WARNING:

- **WARNING FOR YOUNG CHILDREN** - This product contains small components, please ensure that they are kept away from small children while assembling.

1

PARTS LIST

A	B	C	D	E	a	b
						
2PCS	4PCS	2PCS	1PCS	1PCS	1/4*37 4PCS	1/4*30 8PCS
c	d	e	f			
						
4PCS	4PCS	1PCS	1PCS			


IMPORTANT:

Please check parts list before you start to assembly.If parts damaged or missing.Contact your seller for a FREE REPLACEMENT.Please provide your order number,a brief message about the issue,and your shipping address.
Thank you!


2

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED

①




②




3

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED

3



4



IMPORTANT: Please completely tighten all the bolts and nuts.