


# JacksonLux

## Angle Adjustable Magnetic Motion Cabinet Light

Model#CP-CL16-12IN


### PACKAGE CONTENTS




1 x Cabinet Light



1 x Remote Control



2 x Iron Bracket with Adhesive Tape




1 x USB Cord

### How to use the Motion Cabinet Light

**Short press the Mode button:** Short-press the Mode button to power on; the white light flashes once, then enters Motion Sensor Mode. In this mode, long-press the Color Temperature button for approximately 1.5 seconds to achieve stepless dimming (10%-100% brightness adjustment). If the light turns off after sensing, a short press will wake the light for approximately 4 seconds before auto-off, remaining in the sensing state.


**Short press the Mode button again:** The Cabinet light will flash once, then enter Always-On Mode. In this mode, you can press and hold the Color Temperature button for approximately 1.5 seconds to achieve stepless dimming. Short press the Color Temperature button to cycle through colors in the following order: Red → Green → Blue → Color Jump Mode → White → and repeat sequentially. Brightness cannot be adjusted by long pressing in Color Jump Mode.

**Press the Mode button again:** The light will turn off. Subsequent presses of this button will cycle through the above functions in sequence. The cabinet light does not have a memory function. After being turned off and turned back on, it will restore to the default 60% brightness white light.




### How to charge the Motion Cabinet Light

Please use original power adapter and USB cord to charge the motion cabinet light, the indicator turns red when the motion cabinet light is charging, it turns green when the cabinet light is fully charged.




## How to use the Remote Control




## How to install the Motion Cabinet Light


1. Sticks directly to a metal/iron surface.



2. Before installation, please clean the surface first. Attach the iron plates to the magnetic positions and remove the paper from the plates. Then, secure the light in your desired place.



3. A groove on the cabinet light lets you adjust the light bar by hand to change the lighting angle and reach more corners.



## Specification


<b>Lumen:</b> 120lm(Daylight)	<b>Battery:</b> 1000mAh
<b>Light Color:</b> RGB+5000K	<b>Charge Time:</b> Approx.2-3 hours
<b>Weight:</b> 0.46lbs	<b>Product Dimension:</b> 12.01 × 2.60 × 0.97 inch
<b>Runtime:</b> 100% brightwhite -approx.3-4 hrs, longer in RGB colors.	




# WARNING

5mm

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 Hours**.
- **KEEP** new and used batteries **OUT OF REACH** of **CHILDREN**.
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



## CAUTION



This symbol marked on the product indicates "Warning:contains coin battery".

- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above 60° or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

- The compatible battery type is CR2025. The nominal battery voltage is 3V.
- Ensure the batteries are installed correctly according to polarity (+ and -).
- Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries. Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

### SAFETY INFORMATION

- \* Please do not disassemble or modify the led light for any-purpose.
- \* Discontinue use if damaged.
- \* Please check the voltage before installing the light to make sure the voltage is correct
- \* Do not try to replace it on your own.
- \* Clean the light with a soft cloth; Do not spray liquid cleaners or water on the light.
- \* Do not burn any of the items

### CARE AND MAINTENANCE

Using a wet or dry soft cloth, clean the fixture, never spray any liquid cleaner or water directly onto the product.

### WARRANTY

JackonLux provides the 7\*24 customer service and we are pleased to hear from you. This product has 36 months warranty. If you have any questions or problems, please call our customer service department at +86-400-883-1913. You could also contact us at [support@JackonLuxled.com](mailto:support@JackonLuxled.com) .