








1. Let the wire of the fixture ① go through the lampshade ④, lampshade ⑤ and threaded nut ②, rotate threaded nut ② to install all parts together.




can connect more tubes to get the height you need




2. Let the wire go through the tube ⑥, tube ⑦, tube ⑧, rotate to install all tubes to the fixture. (can connect more tubes to get suitable height you need)





3. Let the wire go through the canopy ⑨, rotate to install the canopy ⑨ to the fixture.



Put the bottom plate ③ at an angle into the fabric lampshade ④, then adjust it to level.



suggest to use G45 ping pong bulb



4. Install the bracket to the ceiling junction box with screw ⑪.
 5. Connect the wire to your home line with cap connector ⑫.
 6. Install the fixture to the bracket with cap nut ⑩.
 7. Install the bulb ⑬ and bottom plate ③.

Please read carefully before installation!!!

Note : Please make sure that the electricity is powered off during installation !

Only a professional electrician should install this kind of product !