



ASSEMBLY INSTRUCTION





























Please carefully review the following precautions before proceeding with the installation:

1. The installation process for this product is complex, and it is highly recommended to have at least two individuals working together during the installation.
2. Prior to each step, please refer to the screw hole positions to ensure that the board is aligned correctly according to the images provided in the instruction manual. This will help prevent any errors.
3. In case power tools are used for installation, it is important to tighten the screws intermittently rather than applying excessive force continuously. This precaution will help avoid potential cracks around the screw holes.
4. If you encounter any difficulties or issues during the assembly process, please don't hesitate to reach out to us via email or Amazon message. We assure you that we will address your concerns and provide a solution within 24 hours.







Thank you for your attention to these important instructions.





① x1 	② x1 	③ x1 
④ x1 	⑤ x1 	⑥ x1 
⑦ x1 	⑧ x1 	⑨ x1 
⑩ x1 	⑪ x1 	⑫ x2 
⑬ x1 	⑭ x1 	⑮ x1 
⑯ x1 	⑰ x1 	⑱ x1 
⑲ x1 	⑳ x1 	㉑ x1 
㉒ x1  ㉓ x1 	㉔ x1 	㉕ x1 

Hardware


A	x78 +2(spare)	B	x78 +2(spare)	C	x49 +2(spare)	D	x6	E	x22 +2(spare)	F	x4
											
Ø6x32mm				Ø6x30mm		Ø6x25mm		Ø3.5x12mm			
G	x6	H	x7	I	x1	J	x1	K	x1	L	x1
											
Ø4x35mm								Ø60mm			
N	x1	M	x2	O	x1	P	x1	Q	x2	R	x29 +2(spare)
											
CL	x1	CR	x1	DL	x1	DR	x1				
											
L350mm		L350mm		L350mm		L350mm					

Easy Installation:

-Can rotate the combination dial clockwise or counterclockwise


Set Your Own Password

-The password can be changed instantly
-No special tools required



1000 Combination Options

Change the password simply by pressing the button and setting the code in just a few seconds



Important Notes:

Password Setting

1. Password must be set when the lock is unlocked (default password is 0-0-0)
2. The reset position is located at the small hole on the lower edge of the outer ring; rotate the head until the internal button becomes visible (Can be used with accessory O)
3. Insert a small cylindrical rod into the button, press it down, and rotate the combination dial to align your desired numbers in the center
4. Release the button to complete the password setting



Locking & Unlocking


Rotate to lock the device


After locking, randomly turn one or all combination dials to secure the lock

To unlock, rotate the dials to match the preset password



STEP1



B	x4	A	x4
			
		Ø6x32mm	









STEP2




G	x4
	
Ø4x35mm	

STEP3




DR	x1	DL	x1	E	x4	N	x1
							
L350mm		L350mm		Ø3.5x12mm			

STEP4




A	x11	CR	x1	E	x2
					
Ø6x32mm		L350mm		Ø3.5x12mm	

STEP5




A	x5	CL	x1	E	x2
					
Ø6x32mm		L350mm		Ø3.5x12mm	

STEP6




P	x1	A	x3	M	x2
		Ø6x32mm			


STEP7




C	x2	B	x6
Ø6x30mm			




STEP9




G	x2
	
Ø4x35mm	

STEP8





C	x2
	
Ø6x30mm	

B	x2
	





STEP10




C	x4	B	x7
			
Ø6x30mm			

STEP11




H	x7	C	x2	B	x4
					
		Ø6x30mm			

STEP12




STEP13






C	x16
	
Ø6x30mm	

B	x17
	




STEP14




J	x1	E	x2	A	x12
					
		Ø3.5x12mm		Ø6x32mm	

STEP15




A	x21
	
Ø6x32mm	


STEP16




C	x4	B	x5
			
Ø6x30mm			




STEP17




C	x2	B	x2
			
Ø6x30mm			




STEP18




C	x1	B	x2
			
Ø6x30mm			





STEP19



C	x4	B	x12
			
Ø6x30mm			




STEP20




C	x6	B	x12
			
Ø6x30mm			


STEP21




C	x2	B	x2	A	x2
					
Ø6x30mm				Ø6x32mm	



STEP22



STEP23




STEP24

Note: After the door panel is installed, if the gap of the door is too large or too small, you can adjust this screw to adjust the gap of the door.

3.Adjust this screw to make the door go up or down


2.Adjust this screw to make the door forward or backward

1.Adjust this screw to make the door turn left or right




E	x4	Q	x2
			
Ø3.5x12mm			

STEP25




E	x8
	
Ø3.5x12mm	

STEP26



K	x1
	
Ø60mm	

STEP27



R	x29
	