


Installation instructions


Thank you for purchasing our products. If there is any missing, please kindly send us messages to let us know the name of missing part regarding to the first page of instructions. We will send replacement to you asap. We are concerned about each customer's experience, if there is any loss or damage, please contact us at any time, we will provide effective solutions.
 Customer service E-mail: cservice7@yeah.net
 Please attach your Oder ID so that we can assist you better.




A x 1



B x 1



C x 4



D x 12



8x40mm

E x 12



F x 2



G x 4



H x 2




12mm

I x 2



30mm

J x 2




K x 1



01


Dx6 Ex6

Assembly Tips: You must not tighten any screw yet in this step.



02


Dx3 Ex3



03

Dx3 Ex3

Assembly Tips: When every part is OK, You can tighten all screws in this step.



04

