







ASSEMBLY INSTRUCTION






Patio Dining Chair






PARTS LIST

LABEL		DESCRIPTION	QTY
A		Backrest	2
B		Armrest	4
C		Rear Bumper	2
D		Seat Frame	2
E		Seat Cushion	2





HARDWARE LIST

LABEL		DESCRIPTION	QTY
1	 M6x15	Bolts & Washers	2
2	 M6x35	Bolts & Washers	16
3	 M6x50	Bolts & Washers	4
4		Nut	12
5		Wrench	1
6	 M6	Allen Wrench	1

1



2



3

2 x4



M6x35



6 x1





M6




4


Tighten the screws to 100% tightness



5



6



Note: Each leg has an adjustable footleveler to help level your chair.